## **HOW TO ORDER**

## **Take-Up Frames**

There are two ways to specify DODGE Take-Up Frames. Most of the product offerings have part numbers with listings shown throughout this catalog. Use of part numbers ensures accurate order processing.

When part numbers are not shown, the product may be specified by description or part name. This method is used when ordering units that include modifications or options. To order by description, use the nomenclature key shown on page B19-7 and add any special instructions to the end of the description for options not covered by the nomenclature.

NOTE: All Take-Up Frames, except Bronzoil Take-Ups, are without the Take-Up Bearings. Thus, for a complete Take-Up; order a Take-Up Frame and Take-Up Bearing.

#### The HD Protected Screw Take-Up Frames

HD 200 through HD 350 Take-Up frames will accommodate pillow blocks on saddles which are slotted for two-bolt Pillow Blocks and may be ordered by part numbers. When using four-bolt Pillow Blocks; or on HD frames 400 and larger, please supply:

- 1. Bore size of pillow block
- 2. Type of block (Type E, Double Interlock, SAF-XT, etc.)
- 3. Whether pillow block is two-or four-bolt style
- 4. Frame Travel

### **Modifications:**

For OEM special Take-Up Frames consult DODGE.

Certain modifications are available such as Stainless Steel Screw and non-standard travel lengths.


FEATURES/BENEFITS	HOW TO ORDER/NOMENCLATURE	SELECTION/DIMENSIONS
PAGE B19-2	PAGE B19-7	PAGE B19-8

# www.rodavigo.net +34 986 288118





## **NOMENCLATURE Take-Up Frames**



CP Center Pull Wide Slot Take-Up Frame WS Wide Slot Ball Bearing Take-Up Frame

**WSEZ** Ultra Kleen Wide Slot Ball Bearing Take-Up Frame

NS Narrow Slot Ball Bearing Take-Up Frame LD Light Duty Protected Screw Take-Up Frame

TU Take-Up

HD Heavy Duty Protected Screw Take-Up Frame

TP Top Angle Take-Up Frame

**TPHU** Top Angle Heavy Duty Universal Take-Up Frame

Telescoping Take-Up Frame TS TUA Type A Babbitted Take-Up Bearing TUB Type B Babbitted Take-Up Bearing

**BOTU BRONZOIL Take-Up** 

FR Frame

SSS Stainless Steel Screw

TU = Take-Up When Used As An Abbreviation Through This Section

FEATURES/BENEFITS	HOW TO ORDER/NOMENCLATURE	SELECTION/DIMENSIONS
PAGE B19-2	PAGE B19-7	PAGE B19-8