

Serie FUNCTION

Reguladores de Flujo

Regulación
a
destornillador

8900

Regulador de Flujo unidireccional para cilindro



Código	Ref.	Pack	
8900 M5	0890000001	10	
8900 1/8	0890000002	10	
8900 1/4	0890000003	10	
8900 3/8	0890000004	10	
8900 1/2	0890000005	10	

8910

Regulador de Flujo unidireccional para válvula



Código	Ref.	Pack	
8910 M5	0891000001	10	
8910 1/8	0891000002	10	
8910 1/4	0891000003	10	
8910 3/8	0891000004	10	
8910 1/2	0891000005	10	

8920

Regulador de Flujo bidireccional



Código	Ref.	Pack	
8920 M5	0892000001	10	
8920 1/8	0892000002	10	
8920 1/4	0892000003	10	
8920 3/8	0892000004	10	
8920 1/2	0892000005	10	



Regulación
a
pomo manual

8905

Regulador de Flujo unidireccional para cilindro



Código	Ref.	Pack	
8905 M5	0890500001	10	
8905 1/8	0890500002	10	
8905 1/4	0890500003	10	
8905 3/8	0890500004	10	
8905 1/2	0890500005	10	

8915

Regulador de Flujo unidireccional para válvula



Código	Ref.	Pack	
8915 M5	0891500001	10	
8915 1/8	0891500002	10	
8915 1/4	0891500003	10	
8915 3/8	0891500004	10	
8915 1/2	0891500005	10	

8925

Regulador de Flujo bidireccional



Código	Ref.	Pack	
8925 M5	0892500001	10	
8925 1/8	0892500002	10	
8925 1/4	0892500003	10	
8925 3/8	0892500004	10	
8925 1/2	0892500005	10	

Banjos complementarios

1500

Anillo orientable simple



Código	Ref.	Pack	
1500 4/2,7 M6	0150000002	10	
1500 4/2,7 1/8	0150000003	10	
1500 5/3 1/8	0150000005	10	
1500 6/4 M6	0150000007	10	
1500 6/4 1/8	0150000008	10	
1500 6/4 1/4	0150000009	10	
1500 6/4 3/8	0150000010	10	
1500 8/6 1/8	0150000011	10	
1500 8/6 1/4	0150000012	10	
1500 8/6 3/8	0150000013	10	
1500 8/6 1/2	0150000014	10	
1500 10/8 1/8	0150000015	10	
1500 10/8 1/4	0150000016	10	
1500 10/8 3/8	0150000017	10	
1500 10/8 1/2	0150000018	10	
1500 12/10 3/8	0150000019	10	
1500 12/10 1/2	0150000020	10	
1500 15/12,5 1/2	0150000021	10	

Para los Reguladores de Flujo M5 utilizar el orientable M6.

50505

Anillo orientable simple para Regulador de Flujo de M5



Código	Ref.	Pack	
50505 3 M6	5050500005	10	
50505 4 M6	5050500001	10	
50505 5 M6	5050500003	10	
50505 6 M6	5050500004	10	

50500

Anillo orientable simple



Código	Ref.	Pack	
50500 4 1/8	5050000003	10	
50500 5 1/8	5050000014	10	
50500 5 1/4	5050000015	10	
50500 6 1/8	5050000004	10	
50500 6 1/4	5050000005	10	
50500 8 1/8	5050000006	10	
50500 8 1/4	5050000007	10	
50500 8 3/8	5050000008	10	
50500 10 1/4	5050000009	10	
50500 10 3/8	5050000010	10	
50500 12 3/8	5050000012	10	
50500 12 1/2	5050000021	10	
50500 14 1/2	5050000022	10	

57505

Anillo orientable simple para Regulador de Flujo de M5



Código	Ref.	Pack	
57505 4 M6	5750500001	10	
57505 5 M6	5750500003	10	
57505 6 M6	5750500004	10	

57500

Anillo orientable simple



Código	Ref.	Pack	
57500 4 1/8	5750000003	10	
57500 5 1/8	5750000014	10	
57500 5 1/4	5750000015	10	
57500 6 1/8	5750000004	10	
57500 6 1/4	5750000005	10	
57500 8 1/8	5750000006	10	
57500 8 1/4	5750000007	10	
57500 8 3/8	5750000008	10	
57500 10 1/4	5750000009	10	
57500 10 3/8	5750000010	10	
57500 12 3/8	5750000012	10	
57500 12 1/2	5750000021	10	
57500 14 1/2	5750000022	10	

89505

Anillo orientable simple para Regulador de Flujo de M5



Código	Ref.	Pack	
Tubo Rosca			
*57505 4 M6	5750500001	10	
89505 1/8 M6	8950500001	10	
89505 1/4 M6	8950500003	10	

55500

Anillo orientable simple



Código	Ref.	Pack	
55500 4 M6	5550000002	10	
55500 4 1/8	5550000003	10	
55500 4 1/4	5550000018	10	
55500 5 M6	5550000005	10	
55500 5 1/8	5550000006	10	
55500 5 1/4	5550000007	10	
55500 6 M6	5550000009	10	
55500 6 1/8	5550000010	10	
55500 6 1/4	5550000011	10	
55500 8 1/8	5550000012	10	
55500 8 1/4	5550000013	10	
55500 8 3/8	5550000014	10	
55500 10 1/4	5550000019	10	
55500 10 3/8	5550000015	10	
55500 12 3/8	5550000016	10	
55500 12 1/2	5550000017	10	

Para los Reguladores de Flujo M5 utilizar el orientable M6.

6090

Anillo orientable hembra



Código	Ref.	Pack	
6090 1/8	06090000102NB	10	
6090 1/4	06090000103NB	10	
6090 3/8	06090000104NB	10	