

Table of Contents

page 2

page

	4.1		Push-in fittings
4	4.1.1	951M	Straight male adaptor
5	4.1.2	946M 930M	Straight female adaptor Elbow male adaptor, swivel, brass
6	4.1.3	930P 979P	Elbow male adaptor, swivel, POM Elbow female adaptor, swivel
7	4.1.4	980P 921P	Elbow male adaptor, swivel, long T male adaptor, swivel, POM
8	4.1.5	921M 992P	T male adaptor, swivel, brass Y male adaptor, swivel
9	4.1.6	922P	L male adaptor with off-set leg, swivel
10	4.1.7	958P 955P	Straight connector Elbow connector
11	4.1.8	954P	T-connector
12	4.1.9	982P 908M	Y-connector Stem adaptor
13	4.1.10	959M 945M	Bulkhead connector Bulkhead adaptor
14	4.1.11	952M 952P	Elbow male adaptor, turn-able, brass Elbow male adaptor, turn-able, POM
15	4.1.12	947M 971P	Reducer Plug
	4.2		Push-on fittings
16	4.2.1	151M	Straight male adaptor
17	4.2.2	151M 146M	Straight male adaptor, conical Straight female adaptor
18	4.2.3	130M 130M-D	Elbow male adaptor, swivel Elbow male adaptor, swivel, conical
19	4.2.4	121M 121M	T-male adaptor, swivel T-male adaptor, swivel, conical
20	4.2.5	142M 158M	L-male adaptor with off-set leg, conical Straight connector
21	4.2.6	155M 154M	Elbow connector T-connector
22	4.2.7	145M 156M	Bulkhead adaptor Elbow male adaptor, turn-able
23	4.2.8	152M 153M	Elbow male adaptor, turn-able T male adaptor, turn-able
24	4.2.9	157M	T male adaptor, turn-able
25	4.2.10	151M 130M	Straight male adaptor with spring Elbow male adaptor with spring, swivel
	4.3		Accessories
26	4.3.1	260M	Straight male adaptor, push-on, barbed
27	4.3.2	250M 230M	Nipple Nipple, 3-piece
28	4.3.3	251M 252M	Reducing Nipple, male-male Reducer, female-male
29	4.3.4	253M 254M	Reducer male-female Socket female



Table of Contents

page 3

page

30	4.3.5	255M	Reducer female-female
		257U	Plug
31	4.3.6	262M	Male plug with O-ring seal
		264V	Sealing ring
		265A	Sealing ring
		269N	Sealing ring
	4.4	Airline Adaptors	
32	4.4.1	201M	Elbow, female
		202M	Elbow, female-male
		204M	Elbow, male
33	4.4.2	200M	T, female
		206M	T, male-female-female
		216M	Y, male-female-female
34	4.4.3	203M	Cross, female
	4.5	Automatic Quick couplings	
35	4.5.1	515M, 518M	Straight plug, male
		535M, 538M	Straight plug, female
		565M, 568M	Straight plug, push-on, barbed
36	4.5.2	545M, 548M	Straight plug, push-on
		585M, 588M	Straight plug, push-on with spiral
		551M, 581M	Straight socket, male
37	4.5.3	553M, 583M	Straight socket, female
		586M	Straight socket, push-on, barbed
		554M	Straight socket, push-on
	4.6	Silencers	
38	4.6.1	293U	Silencer, long
		290U	Silencer, short
	4.7	Function fittings	
40	4.7.1	SCU, RCU	Exhaust-Air flow control
41	4.7.2	DR, D	Block form flow regulator
42	4.7.3	VNR, VSR	Non-return valve
43	4.7.4	SEA	Quick exhaust valve
		SSC, SVE	Flow control silencer
	4.8	Pneumatic tube	
44	4.8.1	CPU	PUR Tube
45	4.8.2	CPA	PA Tube
46	4.8.3	CPT	PTFE Tube
		SPA	Spiral Tube