

FLEXIBLE COUPLINGS

CONTENT

	<i>page</i>
1 - GENERAL	
1.1 Function of a flexible coupling	296
1.2 Selection parameters	297
2 - SELECTING A COUPLING	
2.1 Calculating the nominal torque to be transmitted	300
2.2 Safety coefficient	301
2.3 Examples	302
Coupling selection chart	304
3 - EXAMPLES OF INSTALLATION	306
4 - DATA SHEETS	
MINIFLEX®	307
MPP®	311
JUBOFLEX®	315
JUBOFLEX® WITH SEPARATE HUB	317
JUBOFLEX® "S"	321
STRAFLEX®	323
STRAFLEX® WITH SEPARATE HUB	325
CARDAFLEX®	329
RADIAFLEX® RTP	333
AXOFLEX®	337
SPARE PARTS :	
For RADIAFLEX R coupling	342
For GV coupling	345

See current price list for availability of items.

We reserve the right to modify the design and manufacture of the products and materials described in this catalogue.

The pictures and schemas of the products are supplied for information only.