

ACCESORIOS NEUMÁTICA

Enlace rosca macho

Clase Art.
531 00

Medida tubo exterior mm	Rosca" BSP
4	1/8
4	1/4
5	1/8
5	1/4
6	1/8
6	1/4
8	1/8
8	1/4
8	3/8
10	1/4
10	3/8
10	1/2
12	3/8
12	1/2
15	1/2
15	3/4
22	3/4



Adaptador espigo rosca macho

Clase Art.
531 01

Medida espigo exterior mm	Rosca" BSP
4	1/8
4	1/4
5	1/8
5	1/4
6	1/8
6	1/4
8	1/8
8	1/4
8	3/8
10	1/4
10	3/8
10	1/2
12	3/8
12	1/2
15	3/8
15	1/2
22	1/2
22	3/4



Enlace rosca macho metálico

Clase Art.
531 02

Medida tubo exterior mm	Rosca" BSP
4	1/8
4	1/4
6	1/8
6	1/4
8	1/8
8	1/4
8	3/8
10	1/4
10	3/8
10	1/2
12	3/8
12	1/2



Enlace rosca hembra

Clase Art.
531 03

Medida tubo exterior mm	Rosca" BSP
4	1/8
6	1/8
6	1/4
8	1/4
8	3/8
10	5/8
10	1/2



Manguito

Clase Art.
531 04

Medida tubo exterior mm	Medida tubo exterior mm
4	4
5	5
6	6
8	8
10	10
12	12
15	15
22	22
28	28



Manguito reducido

Clase Art.
531 05

Medida tubo exterior mm	Medida tubo exterior mm
6	4
8	4
8	6
10	6
10	8
12	8
12	10



Manguito-espigo reductor

Clase Art.
531 06

Medida espigo exterior mm	Medida tubo exterior mm
5	4
6	4
6	5
8	4
8	5
8	6
10	6
10	8
12	8
12	10
15	10
15	12
22	15
22	18



Codo

Clase Art.
531 07

Medida tubo exterior mm	Medida tubo exterior mm
4	4
5	5
6	6
8	8
10	10
12	12
15	15
22	22
28	28



Codo reducido

Clase Art.
531 08

Medida tubo exterior mm	Medida tubo exterior mm
6	4
8	4
8	6
10	6
10	8
12	8
12	10



Codo con espigo

Clase Art.
531 09

Medida tubo exterior mm	Medida espigo exterior mm
4	4
5	5
6	6
8	8
10	10
12	12
15	15
22	22



Te

Clase Art.
531 10

Medida tubo exterior mm	Medida tubo exterior mm
4	4
5	5
6	6
8	8
10	10
12	12
15	15
22	22
28	28



Tapón

Clase Art.
531 11

	Medida espigo exterior mm
000	4
000	5
000	6
000	8
000	10
000	12
000	15
000	22

