RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Electric Drives and Controls | Hydraulics | Linear Motion and Assembly Technologies | Pneumatics | Service

Rexroth
Bosch Group

Rexroth IndraWorks 12VRS IndraLogic 2G PLC Programming System

R911334390
Edition 01

Application Manual

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Title
Rexroth IndraWorks 12VRS
IndraLogic 2G
PLC Programming System

Type of Documentation
Application Manual

Document Typecode
DOK-IWORKS-IL2GPRO*V12-AP01-EN-P

Internal File Reference
RS-1f979330ef67403c0a6846a00053a898-1-en-US-7

Purpose of Documentation
This documentation describes the PLC programming tool IndraLogic 2G and its usage.
It is also the basis for the online help.

Record of Revision

Edition	Release Date	Notes
Edition 01	09.2011	First edition for IndraWorks 12VRS

Copyright
© Bosch Rexroth AG 2011
Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

Validity
The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Published by
Bosch Rexroth AG
Bgm.-Dr.-Nebel-Str. 2 ■ 97816 Lohr a. Main, Germany
Phone +49 (0)93 52/ 40-0 ■ Fax +49 (0)93 52/ 40-48 85
http://www.boschrexroth.com/
Components & Software BaKo, HBu (vha/MePe)

Note
This document has been printed on chlorine-free bleached paper.

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents

Page

1 About this Documentation ... 17
1.1 Validity of the Documentation ... 17
1.2 Required and Supplementing Documentations ... 17
1.3 Information Representation ... 21
1.3.1 Safety Instructions ... 21
1.3.2 Symbols Used ... 22
1.3.3 Names and Abbreviations ... 22

2 Concepts and Basic Components ... 23
2.1 Concepts and Basic Components, General Information ... 23
2.2 Differences from IndraLogic 1.x ... 24
2.3 Project ... 26
2.4 Supported Programming Languages ... 26
2.5 What is a POU Object ... 27
2.6 Program Organization Units (POU) ... 28
2.6.1 POU, General Information ... 28
2.6.2 Program (PROGRAM) ... 29
2.6.3 Function (FUNCTION) ... 31
2.6.4 Function Block (FUNCTION_BLOCK) ... 33
Function Block, General Information ... 33
Instance of a Function Block ... 34
Calling a Function Block ... 35
Extending a Function Block (EXTENDS) ... 36
Implementing Interfaces (IMPLEMENTS) ... 38
Method Call ... 40
SUPER Pointer ... 41
THIS Pointer ... 42
2.6.5 DUT/Data Type ... 43
2.6.6 Method (METHOD) ... 45
2.6.7 Property (PROPERTY) ... 46
2.6.8 Interface (INTERFACE) ... 49
2.6.9 Action (ACTION) ... 51
2.6.10 External POUs (Functions, Function Blocks, Methods) ... 52
2.6.11 Global Variable List - GVL ... 52
2.6.12 Global Network Variable List - GNVL ... 53
2.6.13 Persistent Variables (VAR PERSISTENT) ... 54
2.6.14 Text List ... 55
2.6.15 Image Pool ... 61
2.6.16 Visualization ... 63
2.6.17 POUs for Implicit Checks ... 63
2.7 Devices in the Project Explorer ... 63
2.8 Application ... 66
2.9 Task Configuration ... 67
2.10 Communication ... 67

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents Page

2.10.1 Communication, General Information ... 67
2.10.2 Control Configuration ... 68
2.10.3 Communication in the Control Link via Gateway ... 68
2.10.4 Data Server ... 71
2.10.5 Network Variables ... 71
Network Variables; Data Exchange between IndraLogic 2G Controls ... 71
Network Variables; Data Exchange between IndraLogic 1.x and 2G Controls ... 76
2.11 Code Generation and Online Change ... 80
2.12 Monitoring ... 82
2.13 Debugging/Troubleshooting ... 82
2.14 Printing ... 83
2.15 Visualization ... 83
2.16 Library Management ... 83
2.16.1 Library Management, Overview ... 83
2.16.2 Installation on the System and Integration (Linking) into a Project ... 84
2.16.3 Referenced Libraries ... 85
2.16.4 Library Versions ... 85
2.16.5 Unique Access to Library Function Blocks (Namespace) ... 86
2.16.6 IndraLogic 1.x Libraries ... 86
2.16.7 External and Internal Libraries or Library Function Blocks, Late Linking ... 87

3 Menu Items ... 89
3.1 Edit ... 89
3.1.1 Edit Menu, Overview ... 89
3.1.2 Undo ... 89
3.1.3 Redo ... 89
3.1.4 Cut ... 90
3.1.5 Copy ... 90
3.1.6 Paste ... 90
3.1.7 Delete ... 91
3.1.8 Rename ... 91
3.1.9 Select All ... 91
3.1.10 Find and Replace ... 91
Overview of Find and Replace ... 91
Find ... 92
Replace ... 95
Search down ... 95
Search down (Selection) ... 95
Search Up ... 96
Search Up (Selection) ... 96
3.1.11 Bookmarks ... 96
Bookmark, Overview ... 96
Switching Bookmark ... 96
Next Bookmark ... 97
Previous Bookmark ... 97
Deleting Bookmark ... 97

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

3.1.12 Insert File as Text ... 97
3.1.13 Browsing ... 97
Browsing, Overview ... 97
Go to Definition ... 97
Displaying Cross References ... 98
3.1.14 Input Assistance ... 98
3.1.15 Declare Variable ... 100
3.1.16 Advanced ... 102
Advanced Overview ... 102
Go to ... 102
Switch to Upper Case ... 102
Switch to Lower Case ... 103
Corresponding Bracket ... 103
Highlight up to Corresponding Bracket ... 103
3.1.17 "List Components" Function ... 103
3.2 View ... 104
3.2.1 View, General Information ... 104
3.2.2 View - Other Windows ... 105
Messages ... 105
Tools ... 106
Cross Reference List ... 107
View - Element Properties ... 108
3.2.3 View - Toolbars ... 109
View - Toolbars, General Information ... 109
Bookmark, Overview ... 109
IndraLogic Overview ... 110
Comparison, Toolbar ... 110
Comparison Results, Toolbar ... 111
3.3 Project ... 111
3.3.1 Archiving and Restoring ... 111
Archiving IndraLogic Projects ... 111
Restoring IndraLogic Projects ... 111
3.3.2 Displaying PLC Objects of an External IndraWorks Project ... 112
3.3.3 Data Transfer ... 115
Data Transfer, Overview ... 115
Importing IndraLogic 1.x Projects ... 116
Importing IndraLogic 2G Projects ... 122
3.4 Create ... 124
3.4.1 Create, Overview ... 124
3.4.2 Compile ... 124
3.4.3 Recompile ... 125
3.4.4 Generate Code ... 125
3.4.5 Clean ... 125
3.4.6 Clean All ... 125
3.5 Debug ... 126
3.5.1 Debugging, Overview ... 126

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents Page

3.5.2 Login ... 127
3.5.3 Logout ... 128
3.5.4 Generating a Boot Application ... 129
3.5.5 Logging out the Current Online User ... 129
3.5.6 Editing Objects Offline in the Online Mode (Hijacking) ... 130
3.5.7 Load ... 132
3.5.8 Online Change ... 133
3.5.9 Start ... 133
3.5.10 Stop ... 133
3.5.11 Single Cycle ... 134
3.5.12 Multiple Download ... 134
3.5.13 Reset Warm ... 135
3.5.14 Reset Cold ... 135
3.5.15 Reset Origin ... 136
3.5.16 Breakpoints ... 136
3.5.17 Breakpoint Positions ... 138
3.5.18 New Breakpoint ... 138
3.5.19 Toggle Breakpoint ... 140
3.5.20 Call Stack ... 141
3.5.21 Monitoring ... 141
3.5.22 Procedure Step ... 142
3.5.23 Single Step ... 142
3.5.24 Execute to Return ... 143
3.5.25 Execute to Cursor ... 143
3.5.26 Determine Next Instruction ... 143
3.5.27 Display Next Instruction ... 143
3.5.28 Write Values for All Online Applications ... 144
3.5.29 Force Values on All Online Applications ... 145
3.5.30 Cancel Forcing for All Values on All Online Applications ... 147
3.5.31 Add All Forces to Monitoring Window ... 148
3.5.32 Sequence Control ... 148
3.5.33 Display Mode ... 151
3.6 Tools ... 151
3.6.1 Comparison of PLC Objects ... 151
Comparison of PLC Objects, General ... 151
Comparison: General Module ... 152
Comparison: Logic ... 153
Comparison: Application ... 154
Comparison: Task Configuration ... 157
Comparison: Task ... 158
Comparison: Folder (Differences with Respect to the IndraWorks Folder) ... 159
Comparison: Data Types ... 159
Comparison: Global Variable List, Persistent Variables, Network Variables ... 161
Comparison: Network Variable Lists, Receiver End ... 162
Comparison: Programs, Function Blocks, Functions ... 163
Comparison: Interfaces, Interface Methods, Interface Properties ... 169

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

Comparison: Library Manager ... 170
Comparison: Library Info ... 172
Comparison: Data Server ... 173
Comparison: Data Source (Data Server) ... 174
Comparison: Symbol Configuration ... 175
Comparison: Visualization Manager ... 175
Comparison: Visualization ... 176
Comparison: Text List ... 177
Comparison: Image Pool ... 177
Comparison: Recipe Manager ... 177
Comparison: Recipe Definition ... 179
Comparison: Devices (Onboard I/O, Inline I/O, Field Busses, ...) ... 179
3.6.2 Simulation ... 183
3.6.3 IndraLogic Project Versions ... 184
3.6.4 Library Repository - Commands ... 185
Library Repository - Commands, General ... 185
Library Repository ... 185
3.6.5 Generating a Library in IndraWorks ... 191
3.6.6 Options ... 197
Options, General Information ... 197
Options, General Settings ... 198
Options, Export ... 198
Options, Visualizations ... 199
Options, Declaration Editor ... 201
Options, SFC ... 202
Options, Smart Coding ... 205
Options, CFC Editor ... 207
Options, FBD, LD and IL ... 207
Options, Device Editor ... 211
Options, Text Editor ... 212
Options, Syntax Highlighting ... 219
Options, SFC Editor ... 219
Options, Libraries ... 222
Options, Converter for IndraLogic 1.x Projects ... 224
Options, IndraLogic 1.x, Settings ... 225
3.7 Library Manager - Commands ... 226
3.7.1 Library Manager - Commands, General Information ... 226
3.7.2 Add Library ... 227
3.7.3 Properties ... 230
3.7.4 Reload Library ... 231
3.8 Image Pool - Commands ... 232
3.8.1 Image Pool - Commands, General Information ... 232
3.8.2 Generating a Global Image Pool ... 232
3.8.3 Generating an Image Pool ... 233
3.9 Recipe Manager - Commands ... 233
3.9.1 Recipe Manager - Commands, General Information ... 233

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents Page

3.9.2 Add Recipe ... 233
3.9.3 Add Variable ... 233
3.9.4 Remove Recipe ... 234
3.9.5 Remove Variables ... 234
3.10 Object Management - Commands ... 234
3.10.1 Object Management - Commands, General Information ... 234
3.10.2 Adding an Object ... 234
3.10.3 Opening an Object ... 236
3.10.4 Implement Interface ... 236
3.10.5 Set Active Application ... 237
3.10.6 Object Properties ... 238
Object Properties, General Information ... 238
Device Properties ... 238
Application Properties ... 240
Object Properties ... 242
File Properties ... 245
Properties of Visualization Objects ... 245
Network Variable Properties ... 246
3.11 FBD/LD/IL - Commands ... 248
3.11.1 FBD/LD/IL - Commands, Overview ... 248
3.11.2 Add Network ... 250
3.11.3 Add Network Below ... 250
3.11.4 Commenting On/Off ... 250
3.11.5 Add Assignment ... 250
3.11.6 Add FB Call ... 251
3.11.7 Add FB Call with EN/ENO ... 254
3.11.8 Add Empty Block ... 254
3.11.9 Add Jump ... 255
3.11.10 Add Jump Label ... 256
3.11.11 Add Return ... 256
3.11.12 Add Block Input ... 257
3.11.13 Add Coil ... 257
3.11.14 Add Set Coil ... 257
3.11.15 Add Reset Coil ... 257
3.11.16 Add Contact ... 257
3.11.17 Add Contact (Right) ... 259
3.11.18 Add Parallel Contact (Below) ... 259
3.11.19 Add Negated Contact ... 259
3.11.20 Add Parallel Negated Contact (Below) ... 259
3.11.21 Add Parallel Contact (Above) ... 259
3.11.22 Add Contacts: Add Below ... 260
3.11.23 Add Contacts: Add Right (After) ... 260
3.11.24 Add Contacts: Add Above ... 261
3.11.25 Add IL Line After ... 261
3.11.26 Delete IL Line ... 261
3.11.27 Negation ... 261

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

3.11.28 Edge Detection ... 262
3.11.29 Set/Reset ... 263
3.11.30 Determine Further Connection ... 264
3.11.31 Insert Line Branching ... 264
3.11.32 Insert Line Branching Above ... 265
3.11.33 Insert Line Branching Below ... 265
3.11.34 Update Parameters ... 265
3.11.35 Remove Unused FB Call Parameters ... 266
3.11.36 View: Show as Function Block Diagram ... 266
3.11.37 View: Show as Ladder Diagram ... 267
3.11.38 View: Show as Instruction List ... 267
3.12 CFC Commands ... 268
3.12.1 CFC Commands, Overview ... 268
3.12.2 Edit Working Sheet ... 269
3.12.3 Negation ... 270
3.12.4 EN/ENO ... 270
3.12.5 Set/Reset ... 271
None (Set/Reset) ... 271
R - Reset ... 272
S - Set ... 272
3.12.6 Execution Order ... 272
At the Beginning ... 272
At the End ... 273
One Ahead ... 273
One Back ... 273
Arrange by Dataflow ... 273
Arrange Topologically ... 275
Set Execution Order ... 276
3.12.7 Edit Parameters ... 276
3.12.8 Connect Selected Connections ... 277
3.12.9 Reset Connections ... 277
3.12.10 Remove Unconnected Connections ... 278
3.13 Sequenctial Function Chart - Commands ... 278
3.13.1 Sequential Function Chart - Commands, Overview ... 278
3.13.2 Initial Step ... 279
3.13.3 Add Input Action ... 279
3.13.4 Add Output Action ... 280
3.13.5 Add Step Transition ... 280
3.13.6 Add Step Transition After ... 281
3.13.7 Parallel ... 281
3.13.8 Alternate ... 282
3.13.9 Add Branch ... 282
3.13.10 Add Branch Right ... 282
3.13.11 Add Action Association ... 283
3.13.12 Add Action Association After ... 284
3.13.13 Add Jump ... 284

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents Page

3.13.14 Add Jump After ... 284
3.13.15 Insert Macro ... 285
3.13.16 Add Macro After ... 285
3.13.17 Display Macro ... 285
3.13.18 Exit Macro ... 286
3.14 Text Lists - Commands ... 286
3.14.1 Text Lists - Overview of Commands ... 286
3.14.2 Create Global Text List ... 287
3.14.3 Add Language ... 287
3.14.4 Remove Language ... 288
3.14.5 Import/Export Text Lists ... 288
3.14.6 Update Visualization Text IDs ... 293
3.14.7 Check Visualization Text IDs ... 293
3.14.8 Remove Unused Text List Entries ... 294
3.15 Trace - Commands ... 294
3.15.1 Trace - Commands, Overview ... 294
3.15.2 Login Trace (Download) ... 294
3.15.3 Start/Stop Trace ... 294
3.15.4 Reset Trigger ... 295
3.15.5 Cursor ... 295
3.15.6 Scrolling with Mouse ... 296
3.15.7 Zooming with Mouse ... 297
3.15.8 Reset Display ... 297
3.15.9 Compress ... 297
3.15.10 Expand ... 298
3.15.11 Multi-Channel ... 298
3.15.12 Online List ... 298
3.15.13 Upload Trace ... 299
3.15.14 Load Trace ... 299
3.15.15 Save Trace ... 299
3.16 Visualization - Commands ... 300
3.16.1 Visualization - Commands, General Information ... 300
3.16.2 Add Visualization Element ... 301
3.16.3 Select All ... 301
3.16.4 Deselect All ... 301
3.16.5 Group ... 301
3.16.6 Ungroup ... 301
3.16.7 Frame Selection ... 302
3.16.8 Interface Editor ... 303
3.16.9 Keyboard Operation ... 303
3.16.10 Element List ... 304
3.16.11 Background ... 304
3.16.12 Order ... 304
Place on Top ... 304
One Level up ... 305
Send to Back ... 305

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

One Level down ... 305
3.16.13 Alignment ... 305
Align Left ... 305
Align at Top ... 305
Align Right ... 305
Align at Bottom ... 306
Center Horizontally ... 306
Center Vertically ... 306
3.16.14 Enable Keyboard Operation ... 306
3.17 Symbol Configuration ... 306

4 Editors ... 309
4.1 CFC Editor ... 309
4.1.1 CFC Editor, General Information ... 309
4.1.2 CFC - Continuous Function Chart - Language ... 310
4.1.3 Cursor Positions in CFC ... 310
4.1.4 CFC Elements/Tools ... 311
4.1.5 Inserting and Arranging Elements ... 315
4.1.6 CFC Editor in Online Mode ... 316
4.2 Data Source Editor ... 318
4.2.1 Data Server, Overview ... 318
4.2.2 Configuring a Data Source ... 318
4.2.3 Adding a Data Server ... 323
4.2.4 Adding a Data Source ... 324
4.2.5 Using Data Sources in Visualizations ... 325
4.3 Declaration Editor ... 326
4.3.1 Declaration Editor, General Information ... 326
4.3.2 Declaration Editor in Online Mode ... 330
4.4 Device Editor ... 331
4.4.1 Device Editor, General Information ... 331
4.4.2 Applications ... 331
4.4.3 Log ... 332
4.4.4 PLC Settings ... 334
4.4.5 Floating Point Exceptions in the PLC program ... 335
4.4.6 Information ... 337
4.5 Data Type Editor ... 338
4.6 FBD/LD/IL Editor ... 339
4.6.1 FBD/LD/IL Editor, Overview ... 339
4.6.2 Programming Languages in the FBD/LD/IL Editor ... 339
Function Block Diagram - FBD ... 339
Ladder diagram - LD ... 340
Instruction list - IL ... 340
4.6.3 Modifiers and Operators in IL ... 341
4.6.4 Working in the FBD and LD Editors ... 343
4.6.5 Working in the IL Editor ... 346
4.6.6 Cursor Positions in FBD, LD and IL ... 351

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents Page

4.6.7 FBD/LD/IL Menu ... 354
4.6.8 FBD/LD/IL Elements ... 355
FBD/LD/IL tools ... 355
Network in FBD/LD/IL ... 356
Assignment in FBD/LD/IL ... 357
Jump in FBD/LD/IL ... 357
Label in FBD/LD/IL ... 357
Function Block Call in FBD/LD/IL ... 358
RETURN Instruction in FBD/LD/IL ... 358
Line Branching/Post-Interconnection in FBD/LD/IL ... 358
Contact in FBD/LD/IL ... 360
Coil ... 361
Set/Reset in FUP/KOP/AWL ... 361
Set/Reset Coils ... 362
4.6.9 FBD/LD/IL Editor in Online Mode ... 362
4.7 GVL Editor ... 367
4.8 Library Manager ... 367
4.8.1 Library Manager, General Information ... 367
4.8.2 Editor Window of the Library Manager ... 368
4.8.3 Library Manager Menu ... 371
4.8.4 Library Information ... 371
4.8.5 Library Info and Access Functions ... 377
Library Info and Access Functions, General Information ... 377
GetCompany ... 378
GetTitle ... 378
GetVersion ... 379
GetBooleanProperty ... 379
GetNumberProperty ... 380
GetVersionProperty ... 380
GetTextProperty ... 381
4.9 Network Variable List Editor ... 382
4.10 Recipe Manager ... 382
4.10.1 Recipe Manager, General Information ... 382
4.10.2 Recipe Definition ... 384
4.10.3 Recipe Manager in Online Mode ... 385
4.11 ST Editor ... 386
4.11.1 ST Editor, Overview ... 386
4.11.2 ST Editor in Online Mode ... 386
4.11.3 Structured Text ST/ExST ... 389
Structured Text ST/Extended Structured Text ExST ... 389
Expressions ... 389
Instructions ... 390
Assignment Operators ... 391
Calling a Function Block in ST ... 392
RETURN Instruction ... 393
IF Instruction ... 393

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

CASE Instruction ... 394
FOR Loop ... 394
WHILE Loop ... 395
REPEAT Loop ... 396
CONTINUE Instruction ... 396
EXIT Instruction ... 396
JMP Instruction ... 397
Comments in ST ... 397
4.12 Symbol Configuration Editor ... 398
4.13 Sequential Function Chart Editor (SFC) ... 399
4.13.1 Sequential Function Chart Editor (SFC), Overview ... 399
4.13.2 SFC - Sequential Function Chart ... 401
4.13.3 Cursor Positions in SFC ... 401
4.13.4 Working in the SFC Editor ... 402
4.13.5 SFC Element Properties ... 404
4.13.6 SFC Elements/Toolbox ... 405
4.13.7 Qualifier for Actions in SFC ... 414
4.13.8 Implicit Variables - SFC Flags ... 414
4.13.9 Processing Sequence in SFC ... 420
4.13.10 SFC Editor in Online Mode ... 421
4.14 Task Management ... 423
4.14.1 Task Management, General Information ... 423
4.14.2 Task Configuration ... 425
Task Configuration, General Information ... 425
Task configuration, "Properties" Tab ... 427
Task Configuration, "Monitoring" Tab ... 427
4.14.3 Task Editor ... 428
Task Editor, General Information ... 428
Task Editor, "Configuration" Tab ... 429
4.15 Trace ... 431
4.15.1 Trace Editor ... 431
Trace Editor, General Information ... 431
Trace Configuration, Variable Settings ... 434
Trace Configuration, Record Settings ... 436
Advanced Trace Settings ... 438
Editing Display Settings (Appearance) ... 439
Appearance of the Y-Axis ... 442
Trace Editor in Online Mode ... 442
Keyboard Operation (Shortcuts) in the Trace Diagram ... 444
4.16 Visualization Editor ... 445
4.16.1 Visualization Editor, General Information ... 445
4.16.2 Visualization Elements, Toolbox ... 446
4.16.3 Selecting Elements ... 449
4.16.4 Position, Size, Alignment, Direction ... 449
4.16.5 Grouping Elements ... 451
4.16.6 Visualization Elements - Properties ... 451

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents

Page

4.16.7 Interface Editor ... 491
4.16.8 Hotkey Configuration Editor ... 494
4.16.9 Element List ... 496
4.17 Visualization Manager ... 496
4.17.1 Visualization Manager ... 496
4.18 Watch List Editor ... 499
4.18.1 Watch List Editor, General Information ... 499
4.18.2 Creating a Watch List ... 499
4.18.3 Watch List in Online Mode ... 500
5 Programming Reference ... 503
5.1 Declaration ... 503
5.1.1 Variable Declaration ... 503
5.1.2 Recommendations for Assigning an Identifier ... 505
Recommendations for Assigning an Identifier, General Information ... 505
Variable Names <Identifiers> ... 505
Variable Names in IndraLogic 2G Libraries ... 507
User-Defined Data Types (DUT) ... 507
User-Defined Data Types (DUT) in IndraLogic 2G Libraries ... 508
POUs (Functions, Function Blocks, Programs, Actions...) ... 509
POUs in IndraLogic 2G Libraries ... 509
Identifiers for Visualizations ... 509
5.1.3 Variable Initialization ... 509
5.1.4 Any Expressions for Variable Initialization ... 510
5.1.5 Declaration Editor ... 510
5.1.6 "Auto Declare" Function ... 510
5.1.7 Short Form Mode ... 511
5.1.8 AT Declaration ... 512
5.1.9 Keywords ... 513
5.1.10 Local Variables (VAR) ... 516
5.1.11 Input Variables (VAR_INPUT) ... 517
5.1.12 Output Variables (VAR_OUTPUT) ... 517
5.1.13 Input/Output Variables (VAR_IN_OUT) ... 517
5.1.14 Global Variables (VAR_GLOBAL) ... 518
5.1.15 Temporary Variables (VAR_TEMP) ... 518
5.1.16 Static Variables (VAR_STAT) ... 518
5.1.17 External Variables (VAR_EXTERNAL) ... 519
5.1.18 Attribute Keywords for Variable Types ... 519
5.1.19 Access Variables ... 519
5.1.20 Remanent Variables (VAR RETAIN, VAR PERSISTENT) ... 519
5.1.21 Constants (VAR CONSTANT), Typed Constants ... 522
5.1.22 Variable Configuration (VAR_CONFIG) ... 523
5.1.23 User-Defined Data Types ... 524
5.1.24 Extendable Functions, PARAMS ... 524
5.1.25 FB_init, FB_reinit Methods ... 524
5.1.26 FB_exit Method ... 526

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

5.1.27 Pragma Statements ... 526
Pragma Statements, Overview ... 526
Message Pragmas ... 527
Attribute Pragmas ... 528
Conditional Pragmas ... 546
5.2 Data Types ... 552
5.2.1 Data Types, General Information ... 552
5.2.2 Basic Data Types ... 553
Basic Data Types, General Information ... 553
BIT ... 553
BOOL ... 553
Bit Sequence ... 554
Integer Data Types ... 554
Floating Point Numbers ... 554
Text Variables ... 555
Time Data Types ... 555
References (REFERENCE) ... 556
Pointer (POINTER) ... 557
5.2.3 User-defined Data Types ... 560
User-Defined Data Types, General Information ... 560
Arrays (ARRAY) ... 560
Structures (STRUCT) ... 563
Union (UNION) ... 564
Enumerations ... 564
Subrange Types ... 566
5.3 IEC Operators and Standard-Extending Functions ... 569
5.3.1 IEC Operators and Standard-Extending Functions, General Information ... 569
5.3.2 Arithmetic Operators ... 569
Arithmetic Operators, Overview ... 569
ADD ... 570
MUL ... 570
SUB ... 570
DIV ... 571
MOD ... 573
MOVE ... 573
SIZEOF ... 574
INDEXOF ... 574
5.3.3 Bit String Operators ... 575
Bit String Operators, Overview ... 575
AND ... 575
ANDN ... 575
OR ... 576
ORN ... 576
XOR ... 576
XORN ... 577
NOT ... 577

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents

Page

5.3.4 Bit Shift Operators ... 577
Bit Shift Operators, Overview ... 577
SHL ... 577
SHR ... 578
ROL ... 579
ROR ... 580
5.3.5 Selection Operators ... 581
Selection Operators, Overview ... 581
SEL ... 581
MAX ... 582
MIN ... 582
LIMIT ... 583
MUX ... 583
5.3.6 Relational Operators ... 584
Relational Operators, Overview ... 584
GT ... 584
LT ... 584
LE ... 585
GE ... 586
EQ ... 586
NE ... 587
5.3.7 Address Operators ... 587
Address Operators, Overview ... 587
ADR ... 587
Content Operators ... 588
BITADR ... 588
5.3.8 Call Operators ... 589
CAL, CALC, CALCN ... 589
5.3.9 Type Conversion Operators ... 590
Type Conversion Operators, Overview ... 590
BOOL_TO Conversions ... 591
TO_BOOL Conversions ... 593
Conversion of Integer Types ... 594
REAL_TO/LREAL_TO Conversions ... 595
TIME_TO/TIME_OF_DAY Conversions ... 596
DATE_TO/DT_TO Conversions ... 597
STRING_TO Conversions ... 599
TRUNC ... 601
TRUNC_INT ... 601
ANY_TO Conversions ... 601
5.3.10 Numeric Operators ... 602
Numeric Operators, Overview ... 602
ABS ... 602
SQRT ... 603
LN ... 603
LOG ... 604

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents
Page

EXP ... 604
SIN ... 605
COS ... 605
TAN ... 606
ASIN ... 606
ACOS ... 607
ATAN ... 607
EXPT ... 608
5.3.11 Namespace Operators ... 608
Namespace Operators, Overview ... 608
Global Namespace Operators ... 609
Namespace for Global Variable Lists ... 609
Library Namespace ... 609
Enumeration Namespace ... 610
5.3.12 IEC-Extending Operands ... 610
IEC-Extending Operands, Overview ... 610
__DELETE ... 610
__ISVALIDREF ... 611
__NEW ... 612
__QUERYINTERFACE ... 614
__QUERYPOINTER ... 615
5.4 Operands ... 615
5.4.1 Operands, General Information ... 615
5.4.2 Constants ... 616
BOOL Constants ... 616
TIME Constants ... 616
DATE Constants ... 617
TIME_OF_DAY Constants ... 617
DATE_AND_TIME Constants ... 618
Number Constants ... 618
REAL/LREAL Constants ... 619
STRING Constants ... 619
WSTRING Constants ... 619
Typed Constants (Typed Literals) ... 620
5.4.3 Variables ... 621
Variables, General Information ... 621
Access to Variables of Arrays, Structures and Function Blocks ... 621
Bit Access to Variables ... 621
5.4.4 Addresses ... 622
Notes on addresses ... 622
Address ... 623
5.4.5 Functions ... 624
Functions ... 624
5.5 Visualization ... 625
5.5.1 Visualization, General Information ... 625
5.5.2 Visualization in IndraLogic 2G ... 625

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Table of Contents

Page

5.5.3 Prerequisites ... 626
5.5.4 Options ... 626
5.5.5 Creating a Visualization Object ... 626
5.5.6 Editing a Visualization ... 627
5.5.7 Visualization Manager ... 627
5.5.8 Start Visualization ... 627
5.5.9 Frames, References, Interfaces, Placeholders ... 628
5.5.10 Text and Language in Visualizations ... 628
5.5.11 Images in a Visualization ... 632
5.5.12 External Data Sources ... 632
5.5.13 Visualization Libraries ... 632
5.5.14 Visualization Profiles ... 633
5.5.15 Visualization Running in the Programming System ... 634
5.5.16 Visualization Elements of Type "Visualization" ... 635
5.5.17 Visualization Elements of Type "Complex Controls Visualization" ... 636
Elements overview ... 636
Configuring the Meter Element ... 637
Configuring the bar display element ... 640
Configuring the Trace Element ... 643
5.5.18 Visualization Elements of Type "Windows Controls" ... 649
Elements overview ... 649
Configuring the table element ... 650
5.5.19 Keyboard Operation in Online Mode ... 657
5.5.20 Note Events and Input Actions ... 658
Overview ... 658
Note the Closing of an Edit Controls (Writing a Variable) ... 658
Note keyboard events ... 661
5.5.21 Input Dialogs ... 663

6 Libraries ... 669
6.1 Libraries, General Information ... 669

7 Service and Support ... 671

Index ... 673

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com