RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



# Index



## Symbols

__DELETE ... 610
__ISVALIDREF ... 611
__NEW ... 612
__QUERYINTERFACE ... 614
__QUERYPOINTER ... 615
%I ... 623
%M ... 623
%Q ... 623

## A

Abbreviations ... 22
About this documentation ... 17
  Information representation ... 21
  Validity of the documentation ... 17
ABS ... 602
Absolute motion of visualization elements ... 451
Absolute value ... 602
Access functions
  GetBooleanProperty ... 379
  GetCompany ... 378
  GetNumberProperty ... 380
  GetTextProperty ... 381
  GetTitle ... 378
  GetVersion ... 379
  GetVersionProperty ... 380
  Library info ... 377
Access right
  Data source variables ... 318
Access rights for symbols ... 398
Access to variable
  Cross reference list ... 107
Access to variables via symbol ... 306
Access variables ... 519
ACOS ... 607
Action ... 51
  Add ... 51
  Call ... 51
ACTION ... 51
Action association ... 284
Action call ... 46
Action call in IL ... 346
Action in SFC ... 284
Action name ... 405, 505
Action qualifier ... 284
Action Qualifier ... 405
Action SFC ... 404
Action status ... 414
Action type ... 494
Action width ... 219
Active
  Watchdog ... 429
Active editor ... 92
Add
  Visualization element ... 446

## A

ADD ... 570
Add action association ... 283
Add action association after ... 284
Add all forces to monitoring window ... 148
Add assignment ... 250
Add branch ... 282
Add branch right ... 282
  Alternate ... 282
  Parallel ... 282
Add coil ... 257
Add contact ... 257
Add contact (right) ... 259
Add contacts, add below ... 260
Add contacts: Add right (after) ... 260
Add contacts: Insert above ... 261
Add device
  Information ... 337
  Logging ... 332
  Ordering number ... 337
Add empty block ... 254
Add FB call with EN/ENO ... 254
Add IL line after ... 261
Add input action ... 279
Add in SFC ... 402
Addition ... 570
Add jump ... 255, 284
Add jump after ... 284
Add jump label ... 256
Add language ... 287
Add library ... 227, 368
  Add ... 227
  Documentation ... 368
  Library\hidden ... 230
  Load ... 231
  Manage ... 368
  Namespace ... 230
  Placeholder ... 227
  Properties... ... 230
  Target system-specific ... 227
  Version management ... 230
Add macro after ... 285
Add method ... 45
Add negated contact ... 259
Add network ... 250
Add network below ... 250
Add object ... 234
Add output action ... 280
Add parallel contact (above) ... 259
Add parallel contact (below) ... 259
Add parallel negated contact (below) ... 259
Add recipe ... 233, 384
Add reset coil ... 257
Address ... 100, 512, 623
Address assignment ... 523

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

A
Address in IL ... 346
Address operator ... 587
Address operator ADR ... 557
Address Operator ADR ... 557
Address prefix ... 623
Add return ... 256
Add set coil ... 257
Add step transition ... 280
Add step transition after ... 281
Add variable ... 233
Add variable to recipe ... 384
Add visualization element ... 446
  Alignment ... 306
  Order ... 305
Add with arguments ... 35
Adjust size of the current CFC ... 269
ADR ... 557, 587
Advanced settings for visualization ... 496
Alarm color ... 451
ALIAS ... 556
Align at bottom ... 306
Align at top ... 305
Align left ... 305
Alignment of visualization elements ... 306, 449
Align right ... 305
Align vertical center ... 306
Alternate branch ... 282
Alternative branching ... 405
Always break ... 138
AND ... 575
ANDN ... 575
AND operator in IL ... 341
ANY_NUM_TO ... 601
ANY_TO ... 601
ANY_TO conversions ... 601
Appearance of the y-axis ... 442
Appearance variables for visualization element 451
Appearance visualization element ... 451
Application ... 66
  Active ... 237
  Arrangement ... 63
  Breakpoint position ... 136
  Father and child ... 63
  Hierarchy ... 63
  Name ... 63
Application hierarchy ... 66
Application properties ... 240
  Boot application ... 241
  Information ... 240
Applications on the control ... 331
Arc cosine value ... 607
Archive and restore ... 111
  Archive IndraLogic projects ... 111
  Restore IndraLogic projects ... 111
Arc sine value ... 606
Arc tangent value ... 607

A
Arithmetic operator ... 569
Arrange by dataflow ... 273
Arrange elements in CFC ... 315
Arrangement of visualization elements ... 449
Arrange topologically ... 275
Array
  Access ... 621
  Declaration ... 100
ARRAY ... 560
  Declaration ... 560
  Initialization ... 560
Array of a structure ... 560
Arrays ... 560
Arrow for trace recording ... 434
ASIN ... 606
Assignment ... 390, 573
Assignment as expression ... 389
Assignment in FBD/LD/IL ... 357
Assignment in LD ... 361
Assignment operator ... 391
Assignments in FBD and LD ... 250
Assign other names ... 556
Association for SFC action ... 284
AT ... 512
ATAN ... 607
AT declaration ... 512
Attach device ... 63
At the beginning ... 272
At the end ... 273
Attribute ... 528
Attribute 'displaymode' ... 531
Attribute 'enable_dynamic_creation' ... 531
Attribute 'expandfully' ... 531
Attribute 'external_name' ... 531
Attribute 'global_init_slot' ... 532
Attribute 'hide_all_locals' ... 534
Attribute 'hide' ... 533
Attribute 'init_namespace' ... 534
Attribute 'init_on_onlchange' ... 535
Attribute 'initialize_on_call' ... 534
Attribute 'instance-path' ... 535
Attribute 'linkalways' ... 536
Attribute 'monitoring' ... 536
Attribute 'no_check' ... 538
Attribute 'no_copy' ... 538
Attribute 'no_init' ... 539
Attribute 'no_virtual_actions' ... 540
Attribute 'no-exit' ... 539
Attribute 'obsolete' ... 542
Attribute 'pack_mode' ... 542
Attribute 'parameterstringof' ... 491, 543
Attribute 'qualified_only' ... 544
Attribute 'reflection' ... 544
Attribute 'relative_offset' ... 545
Attribute 'symbol' ... 545
Attribute call_after_init ... 530

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente






## A

Attribute pragma ... 528
Attributes
  User-defined ... 529
Attributes for variable types ... 519
Attributes of an SFC step ... 404
Author ... 371
Autodeclaration ... 205
Auto declaration ... 510
Autoformat ... 205
Automatic adaptation in online mode ... 496
Automatically update cross references ... 205
Automatic indent ... 212
Automatic POUs for properties access ... 371
Automatic scaling in trace recording ... 434
Automatic scrolling in trace recording ... 434
Available variables ... 318
Available variables for symbol configuration ... 398
Available visualizations ... 302
Average cycle time ... 427
AWL operand ... 346
AWL operator ... 346
Axes for trace recording ... 434
Axis labeling for trace recording ... 434

## B

Background ... 304
Background color for text element ... 219
Background color for trace recording ... 434
Background imaged ... 61
Binary ... 151
BIT ... 553
Bit access ... 325
Bit access to variables ... 621
Bit address ... 588
BITADR ... 588
Bitmap for visualization background ... 61, 304
Bitmap ID variable ... 61
Bitmap ID variable for visualization elements ... 451
bitmapinfo ... 451
Bitmap in visualization ... 451
Bit operation ... 575
Bit shift operator ... 577
Bit string operator ... 575
Block input in FBD/LD/IL ... 257
Block selection ... 326
Bookmarks ... 96
BOOL ... 553
BOOL_TO_DATE ... 591
BOOL_TO_DT ... 591
BOOL_TO_INT ... 591
BOOL_TO_STRING ... 591
BOOL_TO_TIME ... 591
BOOL_TO conversions ... 591
BOOL constants ... 616
Boot application ... 80
Boot project ... 80, 129

## B

Bracket ... 103
Branch ... 282
Branching in SFC ... 405
  Alternative ... 405
  Parallel ... 405
Branching label ... 405
Branch in SFC ... 281
Branch label ... 282
Break ... 138
Breakpoint ... 82
  CFC editor ... 316
  FBD/LD/IL editor ... 362
  SFC ... 421
  ST editor ... 386
Breakpoint condition ... 136
Breakpoint position ... 136, 138
  Condition ... 136
  Current number of hits ... 136
  Delete ... 136
  Delete all ... 136
  Disable ... 136
  Disable all ... 136
  Enable ... 136
  Enable all ... 136
  Properties ... 136
  Source code position ... 136
Breakpoint positions
  CFC editor ... 317
Breakpoints ... 136
Breakpoints dialog ... 136
Break position ... 212
Broadcasting ... 71
Browse ... 97
Buffer size for trace recording ... 434
Bus cycle settings ... 423
Button ... 451
buttonheight ... 451
Button height ... 451
buttonstate variable ... 451
BYTE ... 554
BYTE_TO_BOOL ... 593

## C

CAL ... 251, 589
CALC ... 589
CALCN ... 589
Calculate active transitions only ... 202
call_after_init ... 530
Call a function block ... 35
Call a method ... 45
Call method always cyclically ... 45
  External ... 52
Call operator ... 589
Call parameter ... 35
Call program ... 29
Call stack ... 141


Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## C

CAL operator in IL ... 341
Cancel forcing for all values on all online applications ... 147
CASE instruction ... 390, 394
Center ... 451
Center horizontally ... 306
Center of rotation of a visualization element ... 451
CFC dimensions ... 269
CFC editor ... 309, 310
  Arrange element ... 315
  Breakpoint ... 316
  Breakpoint positions ... 316
  Comment ... 311
  Composition ... 311
  Copy element ... 315
  Cursor positions ... 310
  Delete element ... 315
  Edit element text ... 315
  Execution sequence ... 315
  Function block ... 311
  Input ... 311
  Insert element ... 315
  Jump ... 311
  Label ... 311
  Monitoring ... 316
  Move element ... 315
  Online mode ... 316
  Options ... 207
  Output ... 311
  RETURN ... 311
  Select element ... 315
  Selector ... 311
CFC editor commands ... 268
CFC elements ... 311
CFC execution order ... 268
CFC menu ... 268
  Dimensions ... 269
  Edit working sheet ... 269
  Grid ... 269
  Offset ... 269
  Reset connections ... 277
  Size ... 269
  VAR_INPUT CONSTANT ... 276
CFC tools ... 311
CFC x-offset ... 269
CFC y-offset ... 269
cfg file ... 63
Change namespace ... 230
Character set ... 451
charset ... 451
CheckBounds ... 63
CheckDivByte ... 63
CheckDivDWord ... 63
CheckDivReal ... 63, 571
CheckDivWord ... 63
CheckRangeSigned ... 63, 566

## C

CheckRangeUnsigned ... 63, 566
Check visualization text IDs ... 293
C instruction ... 341
Clean
  Application ... 125
Clean all ... 125
Clean application ... 125
Client height ... 496
Client width ... 496
clipping ... 451
C modifier ... 341
Code completion ... 212
Code generation ... 80, 546
Code generation for SFC ... 202
Code generation offline ... 125
Coil ... 250, 361
Coil/set and reset ... 361
Cold reset ... 519
Cold start ... 135
Color definition ... 451
Color for trace characteristic ... 434
Color for trace recording ... 434
Colors ... 451
Color variables ... 451
Command
  Execute by visualization input ... 451
Command category
  Advanced ... 102
  Browse ... 97
  Compile ... 124
  Debugging ... 126
  Find and replace ... 91
  Image pool ... 232
  Library management ... 185
  Library manager ... 226
  Project ... 234
  Recipe manager ... 233
Command category text lists ... 286
Comment
  FBD/ LD /IL editor ... 207
  Variable declaration ... 100
Comment in FBD/LD/IL ... 356
Commenting for a network ... 250
Commenting On/Off ... 250
Comment in SFC ... 404
Comments in Instruction list ... 340
Comments in ST ... 397
Communication ... 67
Communication data source ... 318
Company ... 227, 371
Comparison
  Application ... 154
  Data server ... 173
  Data source (data server) ... 174
  Data types ... 159

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



C
...Comparison
Devices (onboard I/O, Inline I/O, field busses, …) ... 179
Folder ... 159
General module ... 152
Global variable list, persistent variables, network variables ... 161
Image pool ... 177
Interfaces, interface methods, interface properties ... 169
Library info ... 172
Library manager ... 170
Logic ... 153
Network variable lists, receiver end ... 162
Recipe definition ... 179
Recipe manager ... 177
Symbol configuration ... 175
Task ... 158
Task configuration ... 157
Text list ... 177
Visualization ... 176
Visualization manager ... 175
Comparison of PLC objects ... 151
Compatibility
IndraLogic in different IndraWorks versions ... 184
Compilation ... 80, 546
Compilation commands
Application ... 125
Compilation error ... 125
Compilation information ... 125
Compilation operators ... 546
Compilation options for SFC ... 202
Compilation process ... 80, 546
Compile ... 124
Options for SFC objects ... 202
Compile application
Code generation ... 125
Compile ... 124
Compiled library in IndraWorks ... 191
Compiler definitions ... 546
Compiling messages ... 124
Compiling process ... 526
Composition in CFC ... 311
Concepts ... 23
Condition
Breakpoint ... 136
Conditional call ... 341
Conditional compilation ... 546
Conditional jump ... 341
Conditional pragmas ... 528
Conditional RETURN ... 341
Condition for breakpoint ... 138
Configuration
Floating point exceptions in the PLC program ... 335



...Configuration
Trace ... 434
Configuration data source ... 318
Configuration dialog for devices ... 211
Configuration of a visualization element ... 451
Configuration task ... 429
Configure visualization element ... 451
Properties ... 451
Type ... 451
Configure visualization elements
Alignment ... 449
Background ... 449
Foreground) ... 449
Position ... 449
Sequence ... 449
Size ... 449
Configuring visualization elements
Grouping ... 451
Connect elements with straight lines ... 207
CONSTANT ... 100, 519
Constant inputs in CFC ... 276
Constants ... 522, 616
Date ... 617
Numbers ... 618
REAL and LREAL ... 619
STRING ... 619
Time ... 616, 617
Typed ... 522, 620
WSTRING ... 619
Constants in online mode ... 523
Constant variable ... 100
Declaration ... 100
Constant variables ... 522
Contact ... 360
Container libraries ... 85
Content operator ... 557, 588
CONTINUE instruction ... 396
Continuous function chart ... 310
Options ... 207
Continuous function chart editor ... 309
Control
Logger ... 332
Control configuration ... 68
Conversion ... 222
Conversion of data types ... 590
Conversion of integer types ... 594
Convert among FBD/LD/IL ... 266, 267
Converter for IndraLogic 1.x projects ... 224
Convert keywords to upper case automatically 205
Convert library references ... 222
Coordinates visualization editor ... 451
Coordinate system for trace recording ... 434
Copy ... 90
Copy function block instance ... 526
Copy in IL ... 346
Copy in SFC ... 402

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

C
Copy project ... 26
IndraLogic 1.x ... 26
Copy projects ... 26
Corresponding bracket ... 103
COS ... 605
Cosine ... 607
Cosine value ... 605
Create global text list ... 287
Create recipe ... 384, 451
Creation ... 124
Cross reference list ... 98, 205
Cross references in message box ... 98
Current line ... 212
Current number of hits ... 136
Cursor positions in CFC ... 310
Cursor positions in FBD ... 351
Cursor positions in LD ... 351
Cursor positions in SFC ... 401
Curve ... 446, 451
Cut ... 90
Cut in IL ... 346
Cut in SFC ... 402
Cycle
Execute single cycle ... 134
Cycle time ... 427
Cyclic
Task ... 429
D
D ... 414, 555
d# ... 617
Data exchange ... 71
Dataflow in CFC ... 273
Data server ... 71, 318
Add ... 323
Data source ... 71, 318, 632
Add ... 324
Configuration ... 318
Type ... 324
Visualizations ... 325
Data source editor ... 318
Data source object ... 318
Data source variables ... 318
Data transfer ... 115
Converting library references ... 116
Entering project information ... 116
Importing IndraLogic 1.x projects ... 116
Importing IndraLogic 2G projects ... 122
IndraLogic, overview ... 115
Library paths ... 116
Overwriting objects ... 122
Selecting objects ... 122
Data type ... 330, 522
Cross reference list ... 107
Data type editor ... 338
Data type name ... 505
D
...Data type name
Obsolete pragma ... 542
User-defined ... 524
Warning message ... 542
Data type object ... 43
Extended ... 43
User-defined ... 43
Data types ... 552
Array ... 560
Conversion ... 590
Enumeration ... 564
Pointer ... 557
Reference ... 556
Standard ... 553
STRING ... 555
Structure ... 563
UNION ... 564
User-defined ... 560
WSTRING ... 555
Data Type Unit (DUT) ... 43
DATE ... 555
DATE_AND_TIME ... 555
DATE_AND_TIME constants ... 555, 618
DATE_AND_TIME conversions ... 597
DATE_TO conversions ... 597
DATE constants ... 555, 617
Debug
Watch ... 499
Debugging ... 82, 126
Call stack ... 141
CFC editor ... 316
FBD/LD/IL editor ... 362
ST editor ... 386
Decimal ... 151
Declaration ... 503
Autodeclaration ... 205
Declaration dialog ... 100
Declaration editor ... 326, 510
Options ... 201
Declaration with address assignment ... 512
Auto declaration ... 510
Functions ... 524
Methods ... 524
Short form mode ... 511
Declare unknown variables automatically ... 205
Default namespace ... 371
define ... 546
pragma ... 546
defined ... 546
Define trace variable ... 434
Delete ... 91
Breakpoint ... 136
Delete all ... 136
Delete applications ... 331
Delete bookmark ... 97
Delete element in CFC ... 315

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## D

Delete IL line ... 261
Delete in SFC ... 402
Delete line in IL ... 261
Delete recipe ... 384, 451
Dependencies ... 189
Dereferencing ... 557, 588
Description
  Library information ... 371
Description of trace axis ... 434
Deselect All ... 301
Determine next instruction ... 143
devdesc.xml file ... 63
Device ... 63
Device category ... 337
Device configuration ... 331
Device description ... 63
Device dialog
  Applications ... 331
Device editor ... 63, 331
  Logger ... 332
  Options ... 211
Device name ... 337
Device objects ... 23
Device properties ... 238
Device properties interfaces ... 239
Device repository ... 63
Device-specific library ... 87
Device type ... 337
Device version ... 337
Dialog for breakpoints ... 136
Differences from IndraLogic 1.x ... 24
DINT ... 554
Directory for image files ... 199
Directory for text lists ... 199
Disable
  Breakpoint ... 136
Disable all ... 136
Display cross references ... 98
Display documentation
  Data source ... 318
Display in online mode ... 151
Display invalid variables ... 398
Display macro ... 285
Display next instruction ... 143
Display settings in the trace as standard ... 434
DIV ... 571
Division ... 571
Documentation for library function block ... 368
Documentation of library function blocks ... 83
Download ... 132, 526
  Remanent variables ... 519
DS ... 414
DT ... 555
DT_TO conversions ... 597
dt# ... 618
DUT ... 43

D Index

DUT editor ... 338
DWORD ... 554
Dynamic mapping ... 61
Dynamic test ... 55
Dynamic texts ... 451, 628
Dynamic variables ... 451

## E

Edge detection ... 262
Edit ... 89
  Text editor ... 102
Edit a visualization
  Options ... 626
  Prerequisites ... 626
Edit Control in a visualization ... 658
Edit display settings ... 439
Editing parameters in CFC ... 276
Editor
  Tools ... 106
Editor for network variable lists ... 382
Editor for symbol configuration ... 398
Edit visualization ... 627
Electrical power supply ... 340
Element in visualization ... 451
Element list ... 304, 496
elementlook ... 451
Element name ... 496
Element name in visualization ... 451
Element number in CFC ... 276
Element numbers in CFC ... 315
Element properties
  Data source variables ... 325
Element properties in SFC ... 404
Element properties visualization element ... 451
Elements for FBD/LD/IL ... 355
Elements in SFC ... 405
Element type ... 496
Element types in visualization ... 451
ellipse ... 451
EN/ENO ... 251, 270
EN/ENO in CFC ... 270
enable_dynamic_creation ... 531
Enable all ... 136
Enable input in CFC ... 270
Enable keyboard operation ... 306
Enable lower limit for trace variable ... 434
Enable output in CFC ... 270
Enable upper limit for trace variable ... 434
Enable watchdog ... 429
Enabling a breakpoint ... 136
Encrypt library
  Library information ... 371
END_STRUCT ... 563
END_TYPE ... 560
END_UNION ... 564
END_VAR ... 516

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## E

End of line marker ... 212
Enumeration ... 564
  Initialization ... 564
Enumeration namespace ... 610
EQ ... 586
EQ operator in IL ... 341
Equality ... 586
Error analysis in SFC ... 414
Error in SFC ... 414
Error message ... 105, 527
Error messages during editing ... 386
Event ... 429
  Task ... 429
Event logging ... 332
Event task ... 429
Execute ST code ... 451
Execute ST code via visualization element ... 451
Execute to cursor ... 143
Execute to return ... 143
Execution order in CFC ... 272
Execution sequence in CFC ... 315
EXIT instruction ... 390, 396
Exit macro ... 286
exit method ... 45
Exit method ... 526
EXP ... 604
expandfully ... 531
Explicit type conversion ... 590
Exponential function ... 604
Exponentiation ... 608
Export/import
  IndraLogic ... 115
Export/import of project data ... 115
Export file for text list ... 288
Export only text differences ... 288
Export text list ... 288
Export text lists ... 55
expr ... 546
Expression ... 330, 389
  Evaluation ... 389
EXPT ... 608
ExST ... 389
Extendable function ... 31
Extendable functions ... 524
Extended ... 43
Extended settings for visualization ... 497
Extended structured text ... 389
EXTENDS ... 36, 43
Extension ... 33
Extension of a function block ... 36
external_name ... 531
External data sources ... 632
External event for tasks ... 429
External function ... 52
External function block ... 52
External library ... 87

## E

External method ... 52
External variables ... 519

## F

Falling edge ... 262
FALSE ... 616
FB_EXIT ... 45
FB_exit method ... 526
FB_INIT ... 45
FB_init Method ... 524
FB_reinit method ... 524
FB call in FBD/LD/IL ... 251
FBD ... 339
FBD/LD/IL editor ... 339
  Breakpoint positions ... 362
  Online mode ... 362
FBD/LD/IL editor commands ... 248
FBD/LD/IL insertion positions ... 355
FBD/LD/IL menu ... 354
FBD/LD/IL toolbox ... 355
FBD/LD/IL tools ... 355
  Assignment ... 357
  Function block ... 358
  Jump ... 357
  Label ... 357
  Network ... 356
  RETURN ... 358
FBD commands ... 354
FBD editor ... 343
  Cursor positions ... 351
  Options ... 207
FBD editor commands ... 248
FBD view ... 266
File "commands"
  Library information ... 371
fillattributes ... 451
Fill color ... 451
Find and replace ... 91
Find next ... 92
Find source code position ... 97
Find what ... 92
Fixed size for operand field ... 207
Flags
  SFC ... 202
Flags in SFC ... 414
Floating point exceptions ... 335
Floating point exceptions in the PLC program ... 335
Floating point numbers ... 554
Floating point precision ... 212
Focused border color ... 212
Fold (outline form) ... 212
Font ... 628
Font attributes ... 451
Font flags ... 451
Font for trace recording ... 434
Font for visualization ... 451

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## F

Font height ... 451
Font in text editor ... 212
Font name ... 451
Font style for text element ... 219
Font variables ... 451
Force message output ... 527
Force values
  ST editor ... 386
  Watch list ... 500
Force values on all online applications ... 145
Foreground color for text element ... 219
FOR instruction ... 390
FOR loop ... 394
Format ... 222
  Convert library references ... 222
Format texts ... 55
Formatting specifications for visualization texts 628
Frame ... 451, 491, 628
frameattributes ... 451
Frame attributes ... 451
Frame attributes for visualization elements ... 451
Frame color ... 451
Frame configuration ... 302, 451
Frame in visualization ... 451
Frame reference ... 451
Frame selection ... 302, 446
Free-running task ... 429
Function
  Add ... 31
  Additional outputs ... 517
  Address operator ADR ... 557
  External ... 52
  VAR_OUTPUT ... 31
FUNCTION ... 31
FUNCTION_BLOCK
  EXTENDS ... 36
Function block ... 33
  Add ... 33
  Breakpoint ... 138
  Extension ... 36
  External ... 52
  Method ... 45
  Property ... 45
Function block call ... 35
Function block call in ST ... 392
Function block diagram ... 339
Function block in CFC ... 311
Function block index ... 574
Function block in FBD/LD/IL ... 358
Function block instance ... 35
  Add ... 33
  Interfaces ... 38
  Method call ... 40
  Methods ... 45
  Property ... 46
Function block name ... 505



...Function block name
  Initialization ... 524
  Method before download ... 526
Function block selection of text ... 386
Function call ... 31
Function call in IL ... 346
Function in FBD/LD/IL ... 358
Function name ... 505
Function pointer ... 557, 587
Functions as operands ... 624
Functions for implicit checks ... 63
FUP/KOP/AWL tools
  Line branching/post-interconnection ... 358
Further connection in FBD/LD/IL ... 264

## G

Gateway ... 68
GE ... 586
General device properties ... 238
Generate code ... 125
Generate image pool ... 233
Generating a boot application ... 129
Generating a global image pool ... 232
GE operator in IL ... 341
GetBooleanProperty ... 379
GetCompany ... 378
GetNumberProperty ... 380
get property ... 46
GetTextProperty ... 381
GetTitle ... 378
GetVersion ... 379
GetVersionProperty ... 380
global_init_slot ... 532
GlobalImagePool ... 61, 232
Global image pool ... 61
Global namespace operators ... 609
Global network variable list ... 53
GlobalTextList ... 55, 287, 628
Global variable list ... 52, 367
Global variable list, namespace ... 609
Global variables ... 519
GNVL ... 53
Go to definition ... 97, 107
Go to line ... 102
Go to the source code position ... 136
greater than ... 584
Greater than or equal to ... 586
Grid in the CFC ... 269
Grid in trace recording ... 434
Group
  Visualization elements ... 301
Group according to category ... 227
Group according to company ... 227
Grouping
  Visualization elements ... 451
Grouping according to category ... 185

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## G

GT ..... 584
GT operator in IL ..... 341
GVL ..... 52, 367
GVL editor ..... 367

## H

Hard break ..... 212
hasattribute ..... 546
hastype ..... 546
hasvalue ..... 546
Height of SFC steps ..... 219
Height of the CFC ..... 269
Height of the operand comment field ..... 207
Height of the operand field ..... 207
Height of the operand symbol field ..... 207
Help text ..... 98
Hexadecimal ..... 151
Hidden libraries ..... 87
hide ..... 533
hide_all_locals ..... 534
Highlight color in text editor ..... 212
Highlight current line ..... 212
Highlight up to corresponding bracket ..... 103
Hotkey configuration
  Editor ..... 494
Hotkey configuration, default
  Visualization ..... 498
Hungarian notation ..... 505

## I

I/O configuration ..... 523
  Local ..... 523
Identifier ..... 505
  Multiple use ..... 503
ID for mapping ..... 61
IEC 61131-3 extension ..... 564
  Pointer ..... 557
IEC 61131-3 Extension
  Pointer ..... 557
IEC extending operands ..... 610
IEC operators ..... 569
iecsfc.library ..... 414
IEC step ..... 405
IF ..... 390
IF instruction ..... 390, 393
IL ..... 340
IL commands ..... 354
IL editor ..... 346
  Options ..... 207
IL editor commands ..... 248
IL modifier ..... 341
IL postfix ..... 346
IL prefix ..... 346
IL table editor ..... 346
IL view ..... 267

## I

Image ..... 304, 451
Image element ..... 61
Image file in visualization ..... 451
Image files for visualization ..... 199
Image for visualization background ..... 304
Image pool ..... 61, 232, 632
Image pool commands ..... 232
Image selection ..... 61
Images in a visualization ..... 232, 632
Implement ..... 38
Implementation
  Set breakpoint ..... 138
Implementation language for methods ..... 33
Implemented ..... 33
Implement interfaces ..... 38
IMPLEMENTS ..... 38
Implicit type conversion ..... 590
Implicit variables in SFC ..... 414
  Options ..... 202
Import/export
  IndraLogic ..... 115
Import/Export text lists ..... 288
Import replacement file ..... 288
Import text list ..... 288
Import text lists ..... 55
include ..... 546
Include library ..... 367
Indent ..... 212
Indentation ..... 212
Indent width ..... 212
INDEXOF ..... 574
Index of a function block ..... 574
IndraLogic
  Versions ..... 23
IndraLogic 1.x projects ..... 26
IndraLogic Gateway ..... 68
Inequality ..... 587
info.cfg file ..... 63
Information in the message window ..... 105
Information on the device ..... 337
Information output ..... 527
Information representation
  Names and abbreviations ..... 22
  Safety instructions ..... 21
  Symbols used ..... 22
Inheritance ..... 43
init_namespace ..... 534
init_on_onlchange ..... 535
Initialization ..... 509, 524
  Array ..... 560
  Enumeration ..... 564
  STRUCT ..... 563
  UNION ..... 564
Initialization in case of reset ..... 135
Initialization methods ..... 524
Initialization of function blocks ..... 524

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente





## I

initialize_on_call ... 534
Initialize function blocks
Any expression ... 510
Initializing function blocks
Default value ... 509
User-defined ... 509
Initial step ... 279, 404
init method ... 45
Init step ... 279
Inline monitoring ... 212
CFC editor ... 316
Display ... 212
Enable ... 212
ST editor ... 386
Input/output variables ... 517
Input action ... 404
Input address ... 623
Input assistance ... 98
Input configuration ... 451
Input configuration for visualization elements ... 451
Input in CFC ... 311
Input parameters ... 524
Inputs ... 451
Inputs/outputs of the library function block ... 368
Inputs on the visualization element ... 451
Input support in text editor ... 103
Input variables ... 517
Input variables in the visualization ... 628
Insert device ... 63
Installation ... 63
Representation in the Project Explorer ... 63
Insert element in CFC ... 315
Insert file as text ... 97
Inserting a text file in the editor ... 97
Inserting elements in FBD/LD/IL ... 354
Insert in IL ... 346
Insertion position in FBD/LD/IL ... 355
Insert line branching above in FBD/LD/IL ... 265
Insert line branching below in FBD/LD/IL ... 265
Insert line branching in FBD/LD/IL ... 264
Insert line in IL ... 261
Insert macro ... 285
Insert with arguments ... 98
Installation
Libraries ... 185
Install library ... 185
Dependencies ... 185
Storage location ... 185
Instance ... 34
Set breakpoint ... 138
Visualization ... 628
INSTANCE_OF ... 587
Instance name ... 491
Instance of a function block ... 35
Instance path
Breakpoint position ... 136

## I

...Instance path
Call stack ... 141
For breakpoint position ... 138
instance-path ... 535
Instruction ... 340, 390
Instruction list ... 340
Instruction list view ... 267
INT ... 554
INT_TO_BOOL ... 593
Integer data types ... 554
Intelligent coding ... 103
Intellisense ... 103
Intellisense functionality ... 205
Interface ... 45, 628
Add ... 49
Extend ... 49
Methods ... 49
Visualization ... 628
INTERFACE ... 49
Interface editor ... 491, 628
Interface editor in visualization ... 303
Interface method ... 45
Interface methods ... 38
Interface properties ... 38
Interface property ... 46
Interior rotation ... 451
Internal command ... 451
Internal library ... 85
Interval for task ... 429
Invert in trace recording ... 434
Invisibility of a visualization element ... 451
Invisibility of visualization elements ... 451
Isotropic ... 451
Isotropic visualization elements ... 451
Item background ... 219
Item font style ... 219
Item foreground ... 219

## J

Jitter ... 427
JMP instruction (ST) ... 397
JMP operator in IL ... 341
Jog mode in SFC ... 414
Jump ... 255
Jump in CFC ... 311
Jump in FBD/LD/IL ... 357
Jump in IL ... 346
Jump in SFC ... 284, 405
Jump label ... 255, 256, 284
Jump label in SFC ... 405
Jump to function block ... 97

## K

Keep tab ... 212
Keep tabs ... 212

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## K

Key ... 494
Library information ... 371
Keyboard operation ... 303
Keyboard operation of the visualization ... 657
Keywords ... 513

## L

L ... 414
Label for SFC branch ... 282
Label in CFC ... 311
Label in FBD/LD/IL ... 357
Labeling of axis in trace recording ... 434
Label in SFC
Branching ... 405
Labels in Instruction list ... 340
Ladder diagram ... 340
Language ... 55, 286
Switching language via visualization element ... 451
Language file ... 55
Language files for visualization ... 199
Language in a visualization ... 199
Language selection ... 451
Language selection in visualization ... 628
Late linking ... 87
Layout options for SFC editor ... 219
LD ... 340
LD commands ... 354
Coil ... 361
Contact ... 360
LD editor ... 343
Cursor positions ... 351
Options ... 207
LD editor commands ... 248
LD operator in IL ... 341
LD view ... 267
LE ... 585
Length of the displayed recording ... 434
LE operator in IL ... 341
less than ... 584
Less than or equal to ... 585
Libraries
IndraLogic ... 669
Options ... 222
Libraries for visualizations ... 632
Library ... 83, 367
Conversion ... 222
Installation ... 185
Uninstall ... 185
Library category ... 185, 227
Library database ... 185
Library details ... 185
Library directory ... 83
Library for SFC ... 414
Library information ... 26, 371
Namespace ... 368

## L

Library in IndraWorks ... 191
Library installation ... 185
Library manager ... 226, 367
Commands ... 226
Graphically ... 368
Inputs/outputs ... 368
Library Manager ... 83
Library manager menu ... 371
Library menu ... 83
Container ... 85
Device-specific reference ... 87
External ... 87
General information ... 83
Hidden ... 85
Installation ... 84
Internal ... 85
Namespace ... 86
Referenced ... 85
Target system-specific ... 87
Unique access ... 86
Version ... 85
Library name ... 368
Library namespace ... 368, 609
Library profiles ... 190
Placeholder ... 185
Library properties ... 368
Library reference ... 230
Placeholder ... 227
Library repository ... 185
Library version ... 85, 227, 368
LIMIT ... 583
Limitation ... 583
Line ... 451
Colors ... 212
End marker ... 212
linedirection ... 451
Line in text editor ... 102
Line number ... 212
linestyle ... 451
Line type ... 451
linewidth ... 451
Line width ... 451
linkalways ... 536
LINT ... 554
List components ... 205
List components function ... 103
List components immediately when typing ... 205
LN ... 603
Load ... 132
Remanent variables ... 519
Loading a library ... 231
Load recipe ... 451
Load recipe from file ... 384
Load to the control ... 132
Load trace configuration from file ... 299
Local country language ... 286

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## L

Local variables ... 516
LOG ... 604
Logarithm ... 603
Logger in the runtime system ... 332
Login ... 127, 133
Logout ... 128
Log out current online user ... 129
Log out user ... 129
Look variables ... 451
Lower case letters ... 103
LREAL ... 554
LREAL_TO conversions ... 595
LREAL constants ... 619
LT ... 584
LT operator in IL ... 341
LWORD ... 554

## M

m_references ... 451
Macro editor ... 285
Macro in SFC ... 285, 405
Mapping ... 512
Margin area settings ... 212
Match case ... 92
Matching brackets ... 212
Match whole word ... 92
MAX ... 582
Max. cycle time ... 427
Max. Jitter ... 427
Max. number of tasks ... 427
Maximum active ... 404
Maximum function ... 582
Maximum time for SFC step ... 404
Memory address ... 623
Memory size for visu ... 496
Merge projects ... 26
Message box ... 98
Message category ... 105
Message pragma ... 527
Messages ... 105, 386
Message type ... 527
Message window ... 105
  Pragma ... 527
Method ... 46, 524
  Additional outputs ... 517
METHOD ... 45
Method call ... 45
Method call in application stop ... 45
Method call in IL ... 346
Method implementation language ... 33
Method prototype ... 49
MIN ... 582
Min. cycle time ... 427
Min. Jitter ... 427
Minimum active ... 404
Minimum function ... 582

## M

Minimum time for SFC step ... 404
MOD ... 573
Modifier in IL ... 341
Modulo division ... 573
monitoring ... 536
Monitoring ... 82, 141
  CFC editor ... 316
  FBD/LD/IL editor ... 362
  SFC ... 421
  ST editor ... 386
  Tasks ... 427
  Text editor ... 212
Monitoring a task ... 67
Monitoring format ... 151
Motion of visualization elements ... 451
Mouse actions on visualization element ... 451
Mouse activity in test editor ... 212
MOVE ... 573
Move element in CFC ... 315
Move working sheet origin relatively ... 269
MUL ... 570
MUL operator in IL ... 341
Multi-channel ... 298
Multilingualism ... 55
Multiple download ... 134
Multiple download ... 134
Multiplexer operator ... 583
Multiplication ... 570
Multitasking ... 67
Multi-tasking
  Task configuration ... 425
MUX ... 583

## N

N ... 414
Name
  Device ... 337
  Library ... 368
Name assignment ... 505
Name filter ... 92
Namespace ... 202, 503, 609
  Project ... 371
Namespace for a library ... 609
  Enumeration ... 610
Namespace for library ... 86, 230, 368
Namespace operator ... 609
Naming convention ... 505
NE ... 587
Negated operation ... 341
Negation in CFC ... 270
Negation in FBD/LD/IL ... 261
NE operator in IL ... 341
Nested comments ... 397
Network ... 250, 356
Network comment ... 207, 356
Network communication ... 71

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## N

Network properties ... 71
Network settings ... 71
Network variable list ... 53
Network variable list editor ... 382
Network variables ... 71
  Data exchange between IndraLogic 1.x and 2G controls ... 76
  Data exchange between IndraLogic 2G controls ... 71
New breakpoint ... 136, 138
New recording ... 434
New variable for recording ... 434
Next bookmark ... 97
N modifier ... 341
no_check ... 538
no_copy ... 538
no_init ... 539
no_virtual_actions ... 540
no-exit ... 539
noinit ... 539
no-init ... 539
None ... 271
NOT ... 577
Note events and input actions in the visualization ... 658
Note keyboard events ... 661
Number constants ... 618
Number lines ... 212
Number of cycles ... 427
Number of hits for breakpoint ... 138
Number of objects ... 371
Number of undo steps ... 212
Numeric operators ... 602
NVL ... 53
NVL editor ... 382

## O

Object ... 27
Object orientation ... 23
Object-oriented programming ... 43
Object properties ... 27
Object type ... 371
Object types ... 92
Object types in the project ... 23
Obsolete ... 542
Obsolete pragma ... 542
Offline editing in online mode ... 130
One ahead ... 273
One back ... 273
One level down ... 305
One level up ... 305
Online change ... 80, 127
  Remanent variables ... 519
Online change in an application ... 133
Online commands ... 126

## O

Online mode
  CFC editor ... 316
  Declaration editor ... 330
  FBD/LD/IL editor ... 362
  Keyboard operation ... 657
  Recipe manager ... 385
  ST editor ... 386
  Trace editor ... 442
  Watch list ... 500
Online modus
  SFC editor ... 421
Online view ... 330
Only break if ... 138
onmousedown ... 451
onmouseenter ... 451
onmouseleave ... 451
onmousemove ... 451
onmouseup ... 451
Open object ... 236
Operand
  Options ... 207
Operand in brackets in IL ... 341
Operand in IL ... 346
Operands ... 554, 615
Operator ... 569
  Address ... 587
  Arithmetic ... 569
  Assignment ... 391
  Bit shift ... 577
  Bit string ... 575
  Comparison ... 584
  Namespace ... 608
  Numeric ... 602
  Selection ... 581
  Type conversion ... 590
Operator for pragmas ... 546
Operator in IL ... 346
Options ... 197
  CFC editor ... 207
  Converter for IndraLogic 1.x projects ... 224
  Declaration editor ... 201
  Device editor ... 211
  Export ... 198
  FBD, LD and IL ... 207
  General settings ... 198
  IndraLogic 1.x settings ... 225
  Libraries ... 222
  SFC editor ... 219
  SFC flags ... 202
  SFC objects ... 202
  Smart coding ... 205
  Syntax highlighting ... 219
  Text editor ... 212
  Visualizations ... 199
OR ... 576
Ordering number device ... 337

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## O

Order of visualization elements ... 305
Origin reset ... 519
ORN ... 576
OR operator in IL ... 341
Output action ... 404
Output address ... 623
Output in CFC ... 311
Output variables ... 517

## P

P ... 414
pack_mode ... 542
Parallel branch ... 281
Parallel branching ... 405
parameterstringof ... 491, 543
PARAMS OF ... 524
Parentheses-enclosed expression ... 212
Paste ... 90
Path for files for text lists ... 199
Path for image files ... 199
Pause in SFC ... 414
PERSISTENT ... 100, 519
Persistent variable
  Declaration ... 100
Persistent variables ... 54, 519
Placeholder ... 491, 628
  Visualization ... 628
Placeholder for libraries ... 185
Placeholder for library ... 85, 227
Place on top ... 304
PLC communication
  Gateway ... 68
PLC logger ... 332
PLC logic ... 63
PLC settings ... 334
Pointer ... 557
POINTER ... 557
POINTER TO ... 557
Polygon ... 451
Polyline ... 451
Position ... 451
  Call stack ... 141
Position for breakpoint ... 138
Position of variables ... 107
Position of visualization elements ... 449
Postfix in IL ... 346
POU ... 28
  Breakpoint position ... 136
  Call stack ... 141
  Find ... 97
  For breakpoint position ... 138
POU method ... 45
POU methods ... 38
POU properties ... 27, 38
POU property ... 46
POUs for implicit checks ... 63

## P

Index

POUs for task ... 429
POUs window ... 27
Pragma ... 306, 526
Pragma for data type ... 542
Pragma for message output ... 527
Pragma for symbol configuration
  Conditional ... 546
  define ... 546
  defined ... 546
  hasattribute ... 546
  hastype ... 546
  hasvalue ... 546
  include ... 546
  Obsolete ... 542
  undefine ... 546
  xref ... 546
Pragma operators ... 546
Pragmas for attribute assignment ... 528
Pragma statement ... 526
precompile ... 80
Prefix in IL ... 346
Prepared value ... 144, 330
Prepare value ... 145
Preprocessor ... 526
Previous bookmark ... 97
Printing ... 83
Print visualization
  Element ID ... 494
  Hotkey configuration editor ... 494
  Interface editor ... 491
Priority ... 429
  Task ... 429
Procedure step ... 142
Processing sequence in SFC ... 420
Program ... 29
PROGRAM ... 29
Program call ... 29, 429
Program call in IL ... 346
Program in FBD/LD/IL ... 358
Programming language ... 340
  CFC ... 310
Programming language for methods ... 33
Programming objects ... 23
Programming reference ... 503
Program name ... 505
Program organization unit ... 28
Project ... 26
Project Explorer ... 23
  Rules ... 63
Project organization ... 23
Project settings ... 26
Project statistics ... 371
Project template ... 26
Properties
  Application ... 240
  Breakpoint ... 136

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## P

...Properties
Devices ... 238
Files ... 245
Functions ... 371
Key ... 371
Library information ... 371
Linking to file ... 245
Network variables ... 246
Network variables, receiver end ... 248
Network variables, sender end ... 246
Object ... 27
Object nodes ... 242
Visualization objects ... 245
Properties, application
Compile ... 241
Dynamic memory setting ... 241
General ... 240
Properties, object
Bitmap ... 243
Compile ... 243
General ... 243
Properties dialog visualization ... 451
Visualization element ... 451
Properties of a library ... 368
Properties of an SFC element ... 108, 404
Properties of a visualization element ... 109
Properties of task configuration ... 427
Property ... 46
Method ... 46
PROPERTY ... 46
Publish IEC symbols of the library ... 230

## Q

qualified_only ... 544
Qualifier for SFC actions ... 414
Qualifier in SFC ... 283
Qualifier width ... 219

## R

R ... 272, 414
Read recipe ... 384, 451
REAL ... 554
REAL_TO conversions ... 595
REAL constants ... 619
REAL to INT conversion ... 601
Reboot
Remanent variables ... 519
Recipe ... 233, 384, 451
Recipe commands ... 233
Recipe definition ... 384
Add recipe ... 233
Add variable ... 233
Remove recipe ... 234
Remove variables ... 234
Recipe file ... 384

## R

Recipe management ... 382, 451
Recipe manager ... 233, 382
Recipe name ... 384
Recompile ... 125
Record ... 431
Record for trace
Representation ... 434
Record in each xth cycle ... 434
Recording condition for trace recording ... 434
Recording for trace ... 434
Record settings ... 431
Rectangle ... 451
Redo ... 89
Reference ... 491, 628
Applications ... 331
Data type ... 556
Visualization ... 628
REFERENCE ... 556
Referenced libraries ... 85, 368
References ... 451
References of a variable ... 107
reflection ... 544
Refresh
Application list ... 331
Refresh frame parameter ... 491
Register files for text lists without path ... 199
Register images without path ... 199
Re-initialization ... 136
Relational operators ... 584
relative_offset ... 545
Relative motion ... 451
Relative motion of visualization elements ... 451
Reload library ... 231
Remanent variable
Declaration ... 100
Remanent variables ... 519
Remove FB call parameters ... 266
Remove language ... 288
Remove library ... 368
Remove recipe ... 234, 384
Remove unused FB call parameters ... 266
Remove variable from recipe ... 384
Remove variables ... 234
Rename ... 91
Rename object ... 234
REPEAT instruction ... 390
REPEAT loop ... 396
Replace ... 95
Replace constants ... 523
Repository for libraries ... 185
Representation type for trace characteristic ... 434
Reset ... 272, 391, 519
Reset application ... 135
Reset coil ... 362
Reset cold ... 135
Reset connections ... 277

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## R

Reset display settings ... 434
Reset in SFC ... 414
Reset of a coil ... 362
Reset origin ... 136
Reset task analysis ... 427
Reset task values ... 427
Resetting display settings in trace ... 434
Resetting record settings ... 434
Reset value ... 145
Reset warm ... 135
Resource ... 66
Resource objects ... 23
RETAIN ... 100, 519
Retain variable
  Declaration ... 100
Retain variables ... 519
RET operator in IL ... 341
Return ... 256
RETURN ... 390
RETURN in CFC ... 311
RETURN in FBD/LD/IL ... 358
RETURN instruction ... 393
Rising edge ... 262
ROL ... 579
R operator ... 391
R operator in IL ... 341
ROR ... 580
Rotation ... 579
Rotation of visualization elements ... 451
Rounded rectangle ... 446, 451

## S

S ... 272, 414
Save project and install in library repository
  Library information ... 371
  Summary ... 371
Save recipe ... 451
Save recipe in file ... 384
Save trace..
  Zoom ... 431
Scale division for trace recording ... 434
Scaling ... 451
Scaling of visualization elements ... 451
Scan hardware ... 63
Scheme ... 92
SD ... 414
Search ... 96
Search area ... 92
Search down ... 95
Search down (selection) ... 95
Search for selection ... 92
Search scheme ... 92
Search string ... 92
Search up ... 92, 96
Search up (selection) ... 96
SEL ... 581

## S

Index

Select
  *Visualization elements* ... 301
Select All ... 91, 301
Selected visualizations ... 302
Select element in CFC ... 315
Select insertion position ... 63
Select in SFC ... 402
Selection color for trace recording ... 434
Selection in the FBD/LD editor ... 343
Selection operator ... 581
Select online status ... 236
Selector ... 311
Select visualization elements ... 449, 657
Send to back ... 305
Sensitivity
  Task watchdog ... 429
Sequence control ... 148
Sequential function chart ... 401
Set ... 272, 391
Set/Reset in CFC ... 271
Set/Reset in FBD/LD/IL ... 263
Set/reset in FUP/KOP/AWL ... 361
Set active application ... 237
Set breakpoint ... 140
Set coil ... 362
set property ... 46
Set target system library ... 222
Settings for smart coding ... 205
SFC ... 401
SFC action ... 284
SFCActionControl ... 414
SFCCurrentStep ... 414
SFC default settings ... 202
SFC editor ... 399
  Edit ... 402
SFC editor commands ... 278
SFC editor options ... 219
SFC element properties ... 108
SFC elements ... 405
SFCEnableLimit ... 414
SFCErrorAnalyzationTable ... 414
SFCErrorPOU ... 414
SFCErrorStep ... 414
SFC flags ... 414
SFC flags options ... 202
Sfclec.library ... 202
SFCInit ... 414
SFC jump ... 284
SFC library ... 202, 414
SFC macro ... 285
SFC menu ... 278
SFC options ... 202
SFCPause ... 414
SFC properties ... 202
SFCReset ... 414
SFC step ... 279

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## S

...SFC step
Attributes ... 404
Time monitoring ... 404
SFCTip ... 414
SFCTipMode ... 414
SFC toolbox ... 405
Cursor positions ... 401
Flags ... 414
Implicit variables ... 414
Online mode ... 421
Processing sequence ... 420
Qualifier ... 414
Step attribute ... 404
SFCTrans ... 414
Shift ... 579
SHL ... 577
Short form mode for declaration ... 511
Show as function block diagram ... 266
Show as ladder diagram ... 267
Show documentation ... 98
Show frame ... 451
Show generic configuration editors ... 211
Show network comment ... 207
Show network title ... 207
Show next position ... 107
Show operand comment ... 207
Show PLC objects of an external IndraWorks project ... 112
Show position ... 107
Show previous position ... 107
Show properties in SFC editor ... 219
Show step time ... 219
Show symbol address ... 207
Show symbol comment ... 207
SHR ... 578
Signatures
Applications ... 331
Simple line ... 451
Simulation
IndraLogic ... 183
SIN ... 605
Sine value ... 605, 606
Single cycle ... 134
Single step ... 142
Single step processing ... 82
SINT ... 554
SIZEOF ... 574
Size of a variable ... 574
Size of character buffer ... 496, 497
Size of memory for visu ... 497
Size of visualization elements ... 449
Size visualization ... 496
SL ... 414
Smart coding ... 103, 205
Smart indent ... 212
Soft break ... 212

## S

S operator ... 391
S operator in IL ... 341
Source library ... 222
SQRT ... 603
Square root ... 603
ST ... 386
Standard data types ... 553
Start application ... 133
Starting an application ... 133
Start visualization ... 496, 627
State variables ... 451
State variables for visualization element ... 451
Static ID ... 61, 451
Static mapping ... 61
Static text ... 55
Static texts ... 628
Static variables ... 518
Statistics
Library information ... 371
Status of a task ... 427
Status of SFC actions ... 414
Status of SFC steps ... 414
ST editor ... 386
Breakpoint positions ... 386
Expression ... 389
Extended ... 389
Monitoring ... 386
Step ... 82
Step action ... 405
Step active ... 404
Step attributes ... 219, 404
Step attributes in SFC ... 421
Step by step execution ... 143
Call stack ... 141
Step-by-step processing ... 82
Step-by-step processing in FBD/LD/IL ... 362
Step entry ... 404
Step exit ... 404
Step height ... 219
Step name ... 404
Stepping ... 82
Call stack ... 141
Determine next instruction ... 143
Display next instruction ... 143
Execute to cursor ... 143
Execute to return ... 143
Procedure step ... 142
Single step ... 142
Steps in SFC ... 405
Step status ... 414
Step time ... 219, 414
Step width ... 219
Stop application ... 133
ST operator in IL ... 341
Stopping an application ... 133
Storage location for libraries ... 185

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## S

STRING ... 555, 556
STRING_TO_BOOL ... 593
STRING_TO conversions ... 599
STRING constants ... 619
String length in Inline monitoring ... 212
STRUCT ... 563
  Initialization ... 563
Structure ... 338
  Access ... 621
Structured view ... 98
  Data source ... 318
Structures ... 563
Structure variable in CFC ... 311
SUB ... 570
SUB operator in IL ... 341
Subrange type ... 566
Subrange types ... 566
Subtraction ... 570
Summary
  Library information ... 371
SUPER ... 36
SUPER Pointer ... 41
Support
  see Service Hotline ... 671
Switch bookmark ... 96
Switch frame visualization ... 451
Switch to lower case ... 103
Switch to upper case ... 102
Switch variable ... 451
symbol ... 545
Symbol ... 306, 398
  Access rights ... 398
Symbol configuration ... 398, 404
  IndraLogic 2G ... 306
  xml file ... 306
Symbol configuration editor ... 398
Symbol file ... 398
Symbol in SFC ... 404
Syntax errors ... 386
Syntax highlighting ... 219
SysSem.library
  Application ... 67
System time ... 628

## T

t# ... 616
Tab width ... 212
TAN ... 606
Tangent value ... 606
Tap false ... 451
Tap on enter if captured ... 451
Tap variable ... 451
Target library ... 222
Target system ... 63
Target system-specific library ... 87
Target system-specific library reference ... 227

## T

Index

Task ... 423
  Breakpoint ... 136
  Call stack ... 141
Task configuration ... 67, 428
  Max. number of tasks ... 427
  Monitoring ... 427
  Properties ... 427
Task editor ... 428
  Assign POU ... 429
  Configuration dialog ... 429
  Cycle time ... 427
  Jitter ... 427
  Max. number ... 427
  Monitor ... 427
  Number of cycles ... 427
  Online view ... 427
  Order ... 429
  Status ... 427
Task for trace recording ... 434
  Trace ... 434
Task list ... 429
Task name ... 429
Task properties ... 429
Template ... 26
Temporary variables ... 518
Text ... 527
Text alignment in visualization ... 628
Text area settings ... 212
Text color ... 219
Text editor ... 326
  Colors ... 212
  Font ... 212
  Margin area ... 212
  Options ... 212
Text editor colors ... 212
Text editor commands ... 102
Text editor settings ... 212
Text formatting ... 55, 628
Text in visualization ... 628
Text list ... 55, 287, 628
Text lists ... 286
Text properties ... 451, 628
Text properties for visualization ... 451
Text properties visualization ... 628
Text selection
  Function block selection ... 386
Text variables ... 451
THIS ... 36
THIS pointer ... 42
Time ... 617
TIME ... 555
TIME_OF_DAY ... 555
TIME_OF_DAY constants ... 617
TIME_OF_DAY Constants ... 555
TIME_OF_DAY conversions ... 596
TIME_TO_BOOL ... 593

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## T

TIME_TO conversions ... 596
Time attributes in SFC ... 404
TIME constants ... 616
Time data types ... 555
Time Data Types ... 555
TIME function ... 624
Time monitoring in SFC ... 404
Time of an SFC step ... 219
Timeout in SFC ... 404
Times in SFC ... 404
Time status of an SFC step ... 414
Title ... 371
TO_BOOL conversions ... 593
TOD ... 555
TOD_TO conversions ... 596
tod# ... 617
Toggle breakpoint ... 140
  Active ... 140
  Display ... 138
  Inactive ... 140
  New ... 138
  Position ... 138
  Symbols ... 138
Toggle FBD/LD/IL editor ... 266, 267
Toggle frame visualization ... 302
Toggle variable ... 451
Toolbar
  Bookmarks ... 96
  Comparison ... 110
  Comparison results ... 111
Toolbars
  IndraLogic ... 109, 110
Toolbox ... 106
  CFC ... 309
Toolbox for FBD/LD/IL ... 355
Toolbox in SFC ... 405
Toolbox visualization ... 446
Tools ... 106
Tools for FBD/LD/IL ... 355
Tools for visualization ... 446
Tools in the visualization editor ... 446
Tooltip ... 451
Tooltip text ... 55
Trace ... 294
  Save configuration ... 299
  Scroll ... 444
  Shortcuts ... 444
  Zoom ... 444
Trace buffer ... 431
Trace command
  Compress ... 297
  Cursor ... 295
  Expand ... 298
  Load configuration ... 299
  Login (download) ... 294
  Multi-channel ... 298

## T

...Trace command
  Online list... ... 298
  Reset display ... 297
  Reset trigger ... 295
  Save ... 299
  Scrolling with mouse ... 296
  Start/stop ... 294
  Upload trace ... 299
  Zooming with mouse ... 297
Trace command category ... 294
Trace commands ... 294
Trace configuration ... 434
  Appearance ... 434
  Appearance of the y-axis ... 442
  Display settings ... 439
  Record settings ... 434, 436
  Variable settings ... 434
Trace editor ... 294, 431
Trace file format
  TRACE format: *.trace ... 299
  TXT format: *.txt ... 299
Trace menu ... 431
Trace Settings
  Advanced ... 438
Trace variable ... 431
Trace window ... 431
Transition ... 405
  Code generation ... 202
  Multiple usage ... 405
Transparent ... 451
Transparent color ... 451
Trigger ... 431
Trigger edge for trace recording ... 434
Trigger for trace recording ... 434
Trigger level for trace recording ... 434
Trigger position for trace recording ... 434
Trigger variable ... 434
Troubleshooting ... 82
TRUNC ... 601
TRUNC_INT ... 601
txtrecipe ... 384
TYPE ... 560
  ARRAY ... 560
  STRUCT ... 563
  UNION ... 564
Type conversions ... 590
Typed constants ... 620
Typed literals ... 620

## U

UDINT ... 554
UINT ... 554
ULINT ... 554
undefine ... 546
Undo ... 89, 212
Unfocused border color ... 212

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## U

Ungroup
Visualization elements ... 301
Unicode ... 55
UNION ... 564
Initialization ... 564
Update function block parameters ... 265
Update function block parameters in FBD/LD ... 251
Update parameters ... 251, 358
Update visualization text IDs ... 293
Updating parameters in FBD/LD/IL ... 265
Upper case letters ... 102
Use client size ... 496
Use of variables ... 107
User-defined attributes ... 529
User-defined data type ... 524
User-defined data types ... 560
Use regular expressions ... 92
User input ... 451
Uses as standard ... 434
USINT ... 554

## V

V1.x projects ... 26
Validity range ... 503
Validity ranges of objects ... 63
VAR ... 516
VAR_CONFIG ... 523
VAR_EXTERNAL ... 519
VAR_GLOBAL ... 518
VAR_IN_OUT ... 517
VAR_INPUT ... 517
VAR_INPUT CONSTANT ... 276
VAR_OUTPUT ... 517
VAR_STAT ... 518
VAR_TEMP ... 518
VAR CONSTANT ... 522
Variable ... 503
External ... 519
Global ... 518
Input ... 517
Input/output ... 517
Local ... 516
Output ... 517
Static ... 518
Temporary ... 518
Variable access via symbol ... 306
Variable configuration ... 523
Variable declaration ... 326, 510
Attribute ... 519
Dialog ... 100
Incomplete address ... 523
Variable exchange ... 71
Variable initialization ... 510
Variable name ... 505
Variables ... 621
Access ... 621

## V



...Variables
Bit access ... 621
Implicit in SFC ... 202
Variable settings ... 434
Variable size ... 574
Variable use positions ... 107
Variable value ... 330
VAR PERSISTENT ... 54, 519
VAR RETAIN ... 519
Vendor name ... 337
Version
Library ... 227
Library information ... 371
Version control
Offline edit (hijacking) ... 130
Version management for library ... 230
Version of a library ... 85, 368
View
POUs ... 27
Tools ... 106
View - element properties ... 108
View in FBD ... 266
View in IL ... 267
View in LD ... 267
View options SFC editor ... 219
Visibility ... 100
Visibility of a visualization element ... 451
Visibility of library references ... 230
visu_usewstring ... 55
Visualization ... 625
Absolute movement ... 466
Arrow ... 462
Background ... 304
Bar ... 463
Bitmap ... 304
Bitmap ID variable ... 465
Bitmap info ... 461
Button height ... 461
Button state variable ... 474
Center ... 458
Character buffer ... 496
Clipping ... 475
Close dialog ... 480
Color ... 304
Colors ... 458
Color variables ... 470
Columns ... 455
Configuring the bar display element ... 640
Configuring the meter element ... 637
Configuring the table element ... 650
Configuring the trace element ... 643
Data source ... 318
Default hotkey configuration ... 498
Defining color values ... 490
DialogManager, input dialogs ... 663
Dynamic texts ... 469

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Index

## V

...Visualization
Dynamic values ... 468
Element list ... 304
Element look ... 460
Enable keyboard operation ... 306
Execute ST code ... 480
Font variables ... 469
Frame selection ... 302
Image ... 304
Image ID ... 456
Input dialogs ... 663
Inputs ... 476
Interface editor ... 303
Internal command ... 487
Isotropic ... 474
Keyboard operation ... 303
Label ... 465
Language selection ... 486
Look variables ... 471
m_pLineDirectionVariable ... 473
m_pLineWidthVariable ... 472
m_pPenStyleVariable ... 473
Memory size ... 496
Open dialog ... 485
Position ... 457
References ... 475
Relative movement ... 467
Resulting actions ... 479
Running in the programming system ... 634
Scale ... 464
Scrollbar-specific inputs ... 489
Selection ... 473
State variables ... 472
Switch frame visualization ... 481
Switching variable ... 475
Text lists ... 55
Text properties ... 462
Texts ... 461
Text variables ... 468
Toggle between ... 302
Toggle variable ... 480
Use Unicode character strings: ... 497
Visualization switch ... 485
Write variable ... 483
Visualization background ... 61
Visualization change ... 451
Visualization commands ... 300
Visualization editor ... 300, 445, 491, 627
Element list ... 496
Hotkey configuration ... 494
Interface editor ... 303, 491
Visualization element
Configuration with data source variables ... 325
Selection ... 657
Visualization elements ... 451, 496
Group ... 301

## V

...Visualization elements
Properties ... 109
Type "Complex Control visualization ... 636
Type Windows Controls ... 649
Ungroup ... 301
Visualization type ... 635
Visualization instance ... 628
Visualization interface ... 628
Visualization libraries ... 632
Visualization manager ... 496
Visualization Manager ... 496, 627
Visualization manager editor ... 496
Editor ... 496
Visualization name ... 505
Visualization object ... 626
Create ... 626
Visualization of a trace
Edit Control ... 658
Keyboard operation ... 657
Note keyboard events ... 661
Visualization profiles ... 633
Visualization reference ... 491, 628
Visualizations
Options ... 199
Visualization size ... 497
Visualization text IDs, unused, remove ... 294
VisuElemBase.library ... 632
VisuElemFunctionality.library ... 632
VisuElems.library ... 632
VisuExternals.library ... 632
VisuInputs.library ... 632
VisuInternCommands.library ... 632

## W

Warm reset ... 519
Warm start ... 135
Warning ... 105, 527
Warning for data type ... 542
Watch ... 499
Create watch list ... 499
Watch list ... 500
Watch list in online mode ... 500
Watchdog for tasks ... 429
Watch expression ... 499
Watch list ... 499
Watch list editor ... 499
Watch window ... 500
WHILE instruction ... 390
WHILE loop ... 395
Width of SFC actions ... 219
Width of SFC qualifiers ... 219
Width of SFC steps ... 219
Width of the CFC ... 269
Width of the operand field ... 207
WORD ... 554
Word wrap ... 212

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



## W

Working sheet ... 269
Working sheet in CFC ... 269
Write and read values on the control ... 384
Write recipe ... 384, 451
Write values
  ST editor ... 386
  Watch list ... 500
Write values for all online applications ... 144
Write values to variables ... 384
Write variable ... 451
Write variables in a visualization ... 658
Write variable values ... 384
WSTRING ... 555
WSTRING constants ... 619

## X

X-/y-position in visualization ... 451

## X

X axis in trace ... 434
xml file for symbol configuration ... 306
XOR ... 576
XORN ... 577
XOR operator in IL ... 341
xref ... 546

## Y

Y-axis in trace ... 434

## Z

Zoom to function block ... 97

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente



# Notes

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com

RODAVIGO, S.A.
RODAMIENTOS VIGO, S.A.
www.rodavigo.net
+34 986 288118
Servicio de Att. al Cliente

Rexroth
Bosch Group

Bosch Rexroth AG
Electric Drives and Controls
P.O. Box 13 57
97803 Lohr, Germany
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
Tel. +49 (0)93 52-40-0
Fax +49 (0)93 52-48 85
www.boschrexroth.com/electrics

R911334390

Printed in Germany
DOK-IWORKS-IL2GPRO*V12-AP01-EN-P

Polígono Indutrial O Rebullón s/n. 36416 - Mos - España - rodavigo@rodavigo.com